

LCD (LIQUID CRYSTAL DISPLAY)

LCD (LIQUID CRYSTAL DISPLAY)

PFP:28090

System Description MULTIFUNCTION SWITCH SYSTEM

EKS009BT

Refer to Owner's Manual for multifunction switch operating instructions.

Using the multifunction switch at the center of the instrument panel, the controls of the following systems are centralized:

- Auto A/C system
- Vehicle information system
- Audio system

PRECAUTION OF LCD MONITOR

- When passenger compartment temperature is low, the LCD monitor sometimes dims because of the brightness of the back light (small fluorescent light) integrated into the LCD monitor decrease. In this case, the refreshing rate of the picture also becomes low because of the low response of the LCD monitor. When passenger compartment becomes warm, however, the LCD recovers the normal display.
- Sometimes, black or bright dots peculiar to LCD monitor can be seen on the display.
- Back light sometimes flickers or darkens according to the total consumption hours and the number of ON and OFF switching. In this case, the back light should be replaced (display unit assembly).

POWER SUPPLY AND GROUND

Power is Supplied at All Times

- through 15A fuse (No. 33, located in fuse and fusible link box)
- to display unit terminals 2 and 4
- to audio unit terminals 3 and 4.

When Ignition Switch is in ACC or ON Position, Power is Supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to display unit terminal 6,
- to multifunction switch terminal 6 and
- to audio unit terminal 2.

When Ignition Switch is in ON or START Position, Power is Supplied

- through 10A fuse [No. 10, located in fuse block (J/B)]
- to display unit terminal 5.

Ground is Supplied

- to multifunction switch terminal 1 and
- to display unit terminals 1 and 3
- through body grounds M16, M50, M70 and F115 (Gasoline engine models) or
- through body grounds M16, M50 and M70 (Diesel engine models).

AV COMMUNICATION LINE

Display unit is controlled by the following unit with AV communication line.

- Multifunction switch
- Audio unit

VEHICLE INFORMATION SYSTEM

Refer to Owner's Manual for vehicle information system operating instructions.

Vehicle information system is monitoring to drive information, fuel economy information and maintenance information.

A

B

C

D

E

F

G

H

I

J


DI

L

M

LCD (LIQUID CRYSTAL DISPLAY)

1. Press "INFO" switch to display vehicle information display.
2. Select "Drive", "Fuel Economy" or "Maintenance".




| Display items | | Display/Setting contents |
|--|--------------------------------|--|
| Drive | Elapsed Time | Displays driving time with a range of 0000:00:00 to 9999:59:59. |
| | Driving Distance (km) | Displays driving distance with a range of 00000.0 to 99999.9. |
| | Average speed (km/h) | Displays average speed with a range of 000.0 to 999.9. |
| Fuel Economy | Average Fuel Economy (l/100km) | Displays fuel economy with ignition switch ON, average fuel economy each 30 minutes. |
| | Distance to Empty (km) | Displays possible driving distance with remaining fuel. |
| | Fuel Economy (l/100km) | Displays fuel economy each approx. 100 ms. |
| | Fuel Economy Record (l/100 km) | Displays Average Fuel Consumption History. |
| Maintenance (with Maintenance information*) | Engine oil | Maintenance intervals of engine oil and setting of oil change cycle |
| | Oil Filter | Maintenance intervals of oil filter and setting of filter replacement cycle |
| | Custom 1 | Determines when maintenance intervals are needed. |
| | Custom 2 | Determines when maintenance intervals are needed. |

*: Maintenance information displays the change cycle of engine oil, oil filter, custom 1 and custom 2 on LCD monitor depending on the driving distance specified by a driver or a technician.

Drive Information


1. Select "Drive".
2. Elapsed time, driving distance and average speed are displayed as drive information. When pushing "ENTER", elapsed time, driving distance and average speed are all reset.




LCD (LIQUID CRYSTAL DISPLAY)

Fuel Economy Information

1. Select "Fuel Economy".
2. Average Fuel Economy, Distance to Empty, Fuel Economy are displayed as Fuel Economy information.




3. Select "Fuel Economy Record". The average fuel consumption history will be displayed in graph along with the average for the previous Reset – to – Reset period.



Maintenance Information

1. Select "Maintenance".
2. Engine Oil, Oil Filter, Custom 1 and Custom 2 are displayed as maintenance information.



A
B
C
D
E
F
G
H
I
J
DI
L
M

LCD (LIQUID CRYSTAL DISPLAY)

WARNING INDICATIONS

When combination meter receives warning signal from some control units or sensors, then combination meter warning lamp is illuminated.

Then combination meter sends warning signal to display unit warning indications on the screen.

| Warning indicators | Warning lamps in instrument panel | Warning detection and cancel conditions | | Cases of malfunction |
|---------------------|-----------------------------------|---|---|-----------------------------------|
| ENGINE | ENGINE | Detection condition | Warning lamp ON signal is detected while engine is running. | ECM malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| ENGINE OIL PRESSURE | Engine oil pressure | Detection condition | Warning lamp ON signal is detected for at least approx. 5 seconds while engine is running. | Engine oil pressure decreases. |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| AIR BAG | Air bag | Detection condition | Warning lamp ON signal is detected for at least approx. 10 seconds after ignition switch is turned ON. | SRS air bag system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| LOW BRAKE FLUID | Brake | Detection condition | Warning lamp ON signal (fluid level) is detected. | Low brake fluid level |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| OVERHEATING | - | Detection condition | Engine coolant temperature as being approx. 119°C (246°F) min. | Engine cooling system malfunction |
| | | Cancel condition | Engine coolant temperature as being approx. 105°C (221°F) max. | |
| CHARGE | Charge | Detection condition | Warning lamp ON signal is detected while engine is running. Charging system malfunction | Charging system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| LOW WASHER FLUID | - | Detection condition | Washer liquid level falls below approx. 0.8 ℓ (1-3/8 Imp pt) | Low washer liquid level |
| | | Cancel condition | Except above condition. | |
| LOW FUEL | Fuel level | Detection condition | After warning lamp ON signal is detected, vehicle is driven for over specified distance. [Fuel level: Approx. 9.6 ℓ (8-1/2 Imp pt)] | Low fuel level |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| PARKING BRAKE | Brake | Detection condition | Parking brake ON signal is detected while vehicle is running [approx. 5 km/h (3 MPH) or faster]. | Parking brake remains engaged. |
| | | Cancel condition | Vehicle is stopped, or parking brake OFF signal is detected. | |
| DOOR OPEN | Door | Detection condition | Vehicle is running [approx. 5 km/h (3 MPH) or faster] and door ajar of any of the doors is detected. | Door is open |
| | | Cancel condition | Vehicle is stopped and all the doors lock. | |

LCD (LIQUID CRYSTAL DISPLAY)

| Warning indicators | Warning lamps in instrument panel | Warning detection and cancel conditions | | Cases of malfunction |
|-------------------------------|-----------------------------------|---|--|--------------------------------|
| ABS | ABS | Detection condition | Warning lamp ON signal is detected when engine is running. | ABS control system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| ESP ELECTRONIC CONTROL SYSTEM | ESP | Detection condition | Warning lamp ON signal is detected when engine is running. | ESP system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| CVT ELECTRONIC CONTROL SYSTEM | CVT | Detection condition | Warning lamp ON signal is detected after ignition switch is turned ON. | TCM system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| CRUISE CONTROL SYSTEM | CRUISE | Detection condition | Warning lamp ON signal is detected after ignition switch is turned ON. | ICC system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |

Precautions for Display Unit Replacement


EKS009BU

- Record the following memorized contents before replacing the control unit.
 - <FM-AM>
 - Preset frequency
 - Area for indicating station, selection of overlapped stations
 - <CD>
 - Program status
 - <Sound quality>
 - Volume balance memory set values
 - Equalizer memory set values
 - <Image quality>
 - Brightness of light when ON/OFF
 - Dimming switching
 - Display color switching
- Replace the display unit after disconnecting both battery cables.

LCD (LIQUID CRYSTAL DISPLAY)

Component Parts and Harness Connector and Harness Connector Location

EKS009BV




MKIB0114E

LCD (LIQUID CRYSTAL DISPLAY)

Schematic

EKS009BW



A
B
C
D
E
F
G
H
I
J
DI
L
M








MKWA1021E

LCD (LIQUID CRYSTAL DISPLAY)

Wiring Diagram — COMM —

EKS009BX

DI-COMM-03




REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)






MKWA2481E

LCD (LIQUID CRYSTAL DISPLAY)

DI-COMM-04








- (L) : LHD MODELS
 - (R) : RHD MODELS
 - (SW) : SEDAN AND WAGON
 - (H) : HATCHBACK
- *1 19: (L)
22: (R)
 - *2 18: (L)
21: (R)
 - *3 5: (L)
6: (R)
 - *4 13: (L)
16: (R)
 - *5 W: (SW)
R/L: (H)
 - *6 B: (SW)
R/W: (H)



A
B
C
D
E
F
G
H
I
J
DI
L
M

LCD (LIQUID CRYSTAL DISPLAY)

DI-COMM-05







MKWA2483E

LCD (LIQUID CRYSTAL DISPLAY)

Terminals and Reference Value for Display Unit

EKS009BY

| TERMINALS | | | SIGNAL | CONDITION | | VOLTAGE | |
|-----------|----------------------------|--------|----------------------------------|-----------------|--|--|-----------------|
| (+) | | (-) | | IGNITION SWITCH | OPERATION | | |
| TERMINAL | WIRE COLOR | | | | | | |
| 1 | B | Ground | — | — | — | — | |
| 2 | Y | Ground | Battery power | OFF | — | Battery voltage | |
| 3 | B | Ground | — | — | — | — | |
| 4 | Y | Ground | Battery power | OFF | — | Battery voltage | |
| 5 | Y/G | Ground | Ignition signal | ON | — | Battery voltage | |
| 6 | P | Ground | ACC signal | ACC | — | Battery voltage | |
| 8 | LHD: W/R RHD: Y/R | Ground | Illumination control signal | ON | Lighting switch position | 1st or 2nd | Battery voltage |
| | | | | | | OFF | 0V |
| 11 | L/B | Ground | Vehicle speed signal (2-pulse) | ON | When vehicle speed is approx. 20 km/h (12 MPH) |  <p>ELF1080D</p> | |
| 12 | — | — | Shield ground | — | — | — | |
| 13 | L | Ground | A/C clock signal | ON | — |  <p>SKIA0174E</p> | |
| 14 | L/R | Ground | A/C communication signal (AV-AC) | ON | — |  <p>SKIA0172E</p> | |
| 15 | L/W | Ground | A/C communication signal (AV-AC) | ON | — |  <p>SKIA0173E</p> | |

A

B

C

D

E

F

G

H

I





J

DI

L

M





LCD (LIQUID CRYSTAL DISPLAY)

| TERMINALS | | | SIGNAL | CONDITION | | VOLTAGE |
|-----------|------------|--------|------------------------------|-----------------|---|---|
| (+) | | (-) | | IGNITION SWITCH | OPERATION | |
| TERMINAL | WIRE COLOR | | | | | |
| 16 | R | Ground | Communication signal (AV-ME) | ON | Display the vehicle information screen. |  <p style="text-align: right; font-size: small;">SKIA0169E</p> |
| 17 | — | — | Shield ground | — | — | — |
| 18 | G | Ground | Communication signal (ME-AV) | ON | Perform various settings on the vehicle information screen. |  <p style="text-align: right; font-size: small;">SKIA0170E</p> |
| 19 | L | Ground | Communication signal (-) | ON | — |  <p style="text-align: right; font-size: small;">SKIA0176E</p> |
| 20 | B/W | Ground | Communication signal (+) | ON | — |  <p style="text-align: right; font-size: small;">SKIA0175E</p> |
| 21 | — | Ground | Shield ground | — | — | — |

LCD (LIQUID CRYSTAL DISPLAY)

Terminals and Reference Value for Multifunction Switch

EKS009BZ

| TERMINALS | | | SIGNAL | CONDITION | | VOLTAGE |
|-----------|------------|--------|--------------------------|-----------------|-----------|--|
| (+) | | (-) | | IGNITION SWITCH | OPERATION | |
| TERMINAL | WIRE COLOR | | | | | |
| 6 | P | Ground | ACC | ACC | — | Battery voltage |
| 1 | B | Ground | Ground | ON | — | Approx. 0V |
| 11 | L | Ground | Communication signal (+) | ON | — |  <p>SKIA0175E</p> |
| 12 | B/W | Ground | Communication signal (+) | ON | — |  <p>SKIA0175E</p> |
| 13 | P | Ground | Communication signal (-) | ON | — |  <p>SKIA0176E</p> |
| 14 | L | Ground | Communication signal (-) | ON | — |  <p>SKIA0176E</p> |
| 15 | — | Ground | Shield ground | ON | — | — |
| 16 | — | Ground | Shield ground | ON | — | — |

A

B

C

D

E

F

G

H

I

J

DI

L

M

LCD (LIQUID CRYSTAL DISPLAY)

On Board Self-Diagnosis Function DESCRIPTION

EKS009C0

- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnosis that require operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value.


DIAGNOSIS ITEM

| Mode | | Description | Reference page | |
|-------------------------|----------------------|--|--|---|
| Self-diagnosis | | <ul style="list-style-type: none"> ● Center control unit (display unit) diagnosis. ● Analyzes connection between the display unit and each unit, and operation of each unit. | DI-124. "Self-Diagnosis Mode" | |
| CONFIRMATION/ADJUSTMENT | Display Diagnosis | Display Color Spectrum Bar | Color of display can be checked in this mode. | DI-129. "DISPLAY DIAGNOSIS" |
| | | Display Gradation Bar | Gray gradation of display can be checked in this mode. | |
| | Vehicle Signals | Vehicle Speed | Vehicle speed input signal to center control unit (display unit), can be monitored in this mode. | DI-129. "VEHICLE SIGNALS" |
| | | Light | Light input signal to center control unit (display unit), can be monitored in this mode. | |
| | | IGN | Ignition input signal to center control unit (display unit), can be monitored in this mode. | |
| | Auto Climate Control | | Trouble diagnosis for auto climate control unit (A/C auto amp), can be checked in this mode. | ATC-55. "FUNCTION CONFIRMATION PROCEDURE" |
| Service | | Service schedule can be changed in this mode | DI-130. "SERVICE" | |

Self-Diagnosis Mode OPERATION PROCEDURES


EKS009C1

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
 - Shifting from current screen to previous screen is performed by pressing "PREV" switch.



LCD (LIQUID CRYSTAL DISPLAY)

4. The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.




A

B

C

D

5. Perform self-diagnosis by selecting the "SELF-DIAGNOSIS".
- Self-diagnosis subdivision screen will be shown and the operation enters the self-diagnosis mode.
 - A bar graph shown below the self-diagnosis subdivision screen indicates progress of the diagnosis.




E

F

G

6. When the self-diagnosis completes, optional part confirmation screen will be shown.
- When connection of an optional part is judged malfunction, a screen to check if the optional part is fitted on the vehicle or not will be shown. When fitted, select the switch of the part on the screen and press "END". Then the "Self-diagnosis" screen will be shown.
 - When the optional part is connected normally, the switch for the part will not appear on the screen.



H

I

J


7. On the "Self-diagnosis" screen, each unit name will be colored according to the diagnosis result, as follows.

Green : No malfunctioning.

Yellow : Cannot be judged by self-diagnosis results.

Red : Unit is malfunctioning.

- If several malfunctions are present in a unit, color of its switch on the screen will be either red, yellow, or gray, determined by the malfunction of the highest priority.




L

M

8. Select a switch on the "Self-diagnosis" screen and comments for the diagnosis results will be shown.

- When the switch is green, the following comment will be shown. "Self-diagnosis was successful. Further diagnosis and adjustments are recommended. Follow the "confirmation and adjustments" menu or refer to the service manual".
- When the switch is yellow, the following comment will be shown. "Connection to the following unit is abnormal. See the service manual for further details".
- When the switch is red, the following comment will be shown. "Center Control Unit is abnormal".



DI

LCD (LIQUID CRYSTAL DISPLAY)

CAUTION:

If self-diagnosis cannot be activated, refer to [DI-138, "Self-Diagnosis Does Not Perform"](#).

LCD (LIQUID CRYSTAL DISPLAY)

SELF-DIAGNOSIS RESULT

Quick Reference Table

1. Select an applicable diagnosis No. in the diagnosis result quick reference table.
2. Find estimated malfunctioning system in the diagnosis No. table and perform check by referring to the AV communication line circuit diagram.
3. Turn the ignition switch to OFF and perform self-diagnosis again.

| Screen switch | | | | | Diagnosis No. |
|---------------|-----------------------|----------------------|------------|-----------------|---------------|
| Switch color | Center control unit * | Multifunction switch | Audio unit | CD auto changer | |
| Red | × | | | | 1 |
| Yellow | × | × | | | 2 |
| | × | | × | × | 3 |
| | × | | | × | 4 |
| | × | × | × | × | 5 |

*: Center control unit = Display unit

CAUTION:

When an error is in the AV communication line, it cannot be detected on the screen because self-diagnosis is inoperative.

Self-Diagnosis Codes




| Diagnosis No. | Possible cause | Reference page |
|---------------|---|---|
| 1 | Display unit malfunction. | — |
| 2 | Multifunction switch power supply and ground circuit. | DI-132. "Power Supply and Ground Circuit Check for Multifunction Switch" |
| 3 | Audio unit power supply and ground circuit. AV communication line between multifunction switch and the display unit. Audio unit internal communication circuit. | <ul style="list-style-type: none"> ● AV-48. "Power Supply Circuit Inspection" ● DI-136. "Audio Circuit Check" |
| 4 | CD auto changer power supply and ground circuit. AV communication line between CD auto changer and audio unit. | <ul style="list-style-type: none"> ● AV-48. "Power Supply Circuit Inspection" ● DI-136. "CD Auto Changer Circuit Check" |
| 5 | AV communication line circuit malfunction. | DI-137. "AV Communication Line Check" |

LCD (LIQUID CRYSTAL DISPLAY)

EKS009C2

CONFIRMATION/ADJUSTMENT Mode OPERATION PROCEDURE


1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
 - Shifting from current screen to previous screen is performed by pressing "PREV" switch.
4. The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.
5. When "CONFIRMATION/ADJUSTMENT" is selected on the initial trouble diagnosis screen, the operation will enter the CONFIRMATION/ADJUSTMENT mode. In this mode, check and adjustment of each item will become possible.
6. Select each switch on "CONFIRMATION/ADJUSTMENT" screen to display the relevant diagnosis screen.



LCD (LIQUID CRYSTAL DISPLAY)

DISPLAY DIAGNOSIS

Use this mode to check the display color brightness and setting. The display unit must be replaced if the color brightness and shading are unusual.




CAUTION:

When Display Color Spectrum Bar screen is completed after "BACK" switch is pressed, the screen color changes once. This is normal.

VEHICLE SIGNALS

- In this mode, following input signals to the display unit can be checked on the display.



| Diagnosis item | Display | Condition | Remarks |
|----------------|---------|--|--|
| Vehicle speed | ON | Vehicle speed is greater than 0 km/h (0 MPH). | Changes in indication may be delayed by approx. 1.5 seconds. This is normal. |
| | OFF | Vehicle speed is 0 km/h (0 MPH). | |
| | - | Ignition switch is in "ACC" position. | |
| Light | ON | Lighting switch is 1st or 2nd position. | - |
| | OFF | Lighting switch is "OFF" position. | |
| IGN | ON | Ignition switch is in "ON" position. | - |
| | OFF | Ignition switch is in "ACC" or "OFF" position. | |

- If vehicle speed is NG, refer to [DI-133, "Vehicle Speed Signal Check/LHD Models"](#) or [DI-134, "Vehicle Speed Signal Check/RHD Models"](#).
- If light is NG, refer to [DI-135, "Illumination Control Signal Check"](#).
- If IGN is NG, refer to [DI-135, "Ignition Signal Check"](#).


LCD (LIQUID CRYSTAL DISPLAY)

SERVICE

- In this mode, service schedule can be set on this display.

NOTE:

- To set service schedule, change journey distance.
- When the indicator of “Service Information Display” is set green, the color of the journey distance marker will be red. And automatically service information screen will be displayed when journey distance is reached on service schedule.



LCD (LIQUID CRYSTAL DISPLAY)

Power Supply and Ground Circuit Check for Display Unit

EKS009C3

1. CHECK FUSE

Check that the following fuses in display are blown.

| Unit | Power source | Fuse No. |
|---------|---------------------------|----------|
| Display | Battery power | 33 |
| | Ignition switch ACC or ON | 1 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3](#), "POWER SUPPLY ROUTING".

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect display connector.
2. Check voltage between display unit harness connector and ground.

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (Wire color) | | | | |
| M61 | 2 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 4 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 6 (P) | Ground | 0V | Battery voltage | Battery voltage |



OK or NG


OK >> GO TO 3.

NG >> Check harness for open or short between display and fuse.

3. GROUND CIRCUIT CHECK

Check continuity between display unit and ground.

| Terminals | | (-) | Continuity |
|-----------|-----------------------|--------|------------|
| (+) | | | |
| Connector | Terminal (wire color) | | |
| M61 | 1 (B) | Ground | Yes |
| | 3 (B) | Ground | Yes |



OK or NG

OK >> Inspection end.

NG >> Check ground harness.

LCD (LIQUID CRYSTAL DISPLAY)

Power Supply and Ground Circuit Check for Multifunction Switch

EKS009C4

1. CHECK FUSES

Check the fuse below.

| Unit | Power source | Fuse No. |
|----------------------|---------------------------|----------|
| Multifunction switch | Ignition switch ACC or ON | 1 |

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3](#), "[POWER SUPPLY ROUTING](#)".

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect multifunction switch connector.
2. Check voltage between multifunction switch and ground.

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (Wire color) | | | | |
| M49 | 6 (P) | Ground | 0V | Battery voltage | Battery voltage |



OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between multifunction switch and fuse.

3. GROUND CIRCUIT CHECK


1. Check continuity between multifunction switch harness connector M49 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Inspection end.

NG >> Check ground harness.



LCD (LIQUID CRYSTAL DISPLAY)

EKS009C5

Vehicle Speed Signal Check/LHD Models

1. HARNESS CHECK

1. Disconnect display unit connector and combination meter connector.
2. Check the following.
 - Continuity between display unit harness connector M61 terminal 11 (L/B) and combination meter harness connector M37 terminal 34 (L/B).


Continuity should exist.

- Continuity between display unit harness connector M61 terminal 11 (L/B) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 2.
- NG >> Replace harness or connector.





2. VEHICLE SPEED SIGNAL CHECK

Connect combination meter connector and display unit connector.

Ⓜ With CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check signal between display unit harness connector M61 terminal 11(L/B) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)

11- Ground:




⊗ Without CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check voltage between display unit harness connector M61 terminal 11(L/B) and ground when rotating wheels with engine at idle.

Voltage: Approximately 0 – 5V

OK or NG

- OK >> Replace display unit.
- NG >> Check combination meter system. Refer to [DI-36, "Combination Meter Self-Diagnosis"](#).



LCD (LIQUID CRYSTAL DISPLAY)

EKS009C6

Vehicle Speed Signal Check/RHD Models

1. HARNESS CHECK

1. Disconnect display unit connector and combination meter connector.
2. Check the following.
 - Continuity between display unit harness connector M61 terminal 11 (L/B) and combination meter harness connector M37 terminal 47 (L/B)


Continuity should exist.

- Continuity between display unit harness connector M61 terminal 11 (L/B) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 2.
- NG >> Replace harness or connector.



MKIB0209E


2. VEHICLE SPEED SIGNAL CHECK

Connect combination meter connector and display unit connector.


With CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check signal between display unit harness connector M61 terminal 11(L/B) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)

11- Ground:



ELF1080D



MKIB0723E


Without CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check voltage between display unit harness connector M61 terminal 11(L/B) and ground when rotating wheels with engine at idle.

Voltage: Approximately 0 – 5V

OK or NG

- OK >> Replace display unit.
- NG >> Check combination meter system. Refer to [DI-77, "Combination Meter Self-Diagnosis"](#).



MKIB0208E

LCD (LIQUID CRYSTAL DISPLAY)

Illumination Control Signal Check

EKS009C7

1. ILLUMINATION CONTROL SIGNAL CHECK

1. Check voltage between display unit and ground.


| Terminals | | (-) | Condition | Voltage [V] |
|-----------------------|----|--------|-------------------------------------|-----------------|
| (+) Connector | | | | |
| Terminal (wire color) | | | | |
| M61 | 8* | Ground | Lighting switch 1st or 2nd position | Battery voltage |
| | | | OFF | Approx.0 |

*: LHD: (W/R), RHD: (Y/R)

OK or NG

OK >> Replace display unit.

NG >> Check harness for open or short between display unit and lighting switch.



Ignition Signal Check

EKS009C8

1. IGNITION SIGNAL CHECK


1. Turn ignition switch ON.
2. Disconnect the display unit connector.
3. Check voltage between display unit harness connector M61 terminal 5 (Y/G) and ground.

Battery voltage should exist.

OK or NG

OK >> Replace display unit.

NG >> Check harness for open or short between display unit and fuse.



LCD (LIQUID CRYSTAL DISPLAY)


Audio Circuit Check

EKS009C9

1. AUDIO UNIT CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect audio unit connector.
3. Check continuity between multifunction switch and audio unit.

| Terminals | | | | Continuity |
|----------------------|-----------------------|------------|-----------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |



4. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

OK or NG

- OK >> Replace audio unit.
 NG >> Replace harness or connector.


CD Auto Changer Circuit Check

EKS009CA

1. CD AUTO CHANGER CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.

| Terminals | | | | Continuity |
|------------|-----------------------|-----------------|-----------------------|------------|
| Audio unit | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R/G) | B31 | 28 (R/G) | Yes |
| | 21 (R/L) | | 29 (*1) | |
| | 22 (R/W) | | 30 (*2) | |



- *1: Sedan and wagon models (W)
 Hatchback models (R/L)
 *2: Sedan and wagon models (B)
 Hatchback models (R/W)

3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 20 (R/G) | Ground | No |
| | 21 (R/L) | | |
| | 22 (R/W) | | |

OK or NG

- OK >> Replace CD auto changer.
 NG >> Replace harness or connector.

LCD (LIQUID CRYSTAL DISPLAY)

EKS009CB

AV Communication Line Check

1. MULTIFUNCTION SWITCH CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect display unit connector and multifunction switch connector.
3. Check continuity between display unit and multifunction switch.

| Terminals | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M61 | 19 (L) | M49 | 14 (L) | Yes |
| | 20 (B/W) | | 12 (B/W) | |


4. Check continuity between display unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M61 | 19 (L) | Ground | No |
| | 20 (B/W) | | |

OK or NG

OK >> GO TO 2.

NG >> Replace harness or connector



2. AUDIO UNIT CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect audio unit connector.
3. Check continuity between multifunction switch and audio unit.

| Terminals | | | | Continuity |
|----------------------|-----------------------|------------|-----------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |


4. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

OK or NG

OK >> GO TO 3.

NG >> Replace harness or connector.



LCD (LIQUID CRYSTAL DISPLAY)

3. CD CHANGER CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.

| Terminals | | | | Continuity |
|------------|--------------------------|-----------------|--------------------------|------------|
| Audio unit | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R/G) | B31 | 28 (R/G) | Yes |
| | 21 (R/L) | | 29 (*1) | |
| | 22 (R/W) | | 30 (*2) | |

*1: Sedan and wagon models (W)
Hatchback models (R/L)

*2: Sedan and wagon models (B)
Hatchback models (R/W)

3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|--------------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 20 (R/G) | Ground | No |
| | 21 (R/L) | | |
| | 22 (R/W) | | |

OK or NG

OK >> Replace display unit.

NG >> Replace harness or connector.

Self-Diagnosis Does Not Perform

EKS009CC

1. MULTIFUNCTION SWITCH CHECK

Check multifunction switch power and ground circuit. Refer to [DI-132, "Power Supply and Ground Circuit Check for Multifunction Switch"](#) .

>> GO TO 2.

2. DISPLAY UNIT CHECK

Check display unit power and ground circuit. Refer to [DI-131, "Power Supply and Ground Circuit Check for Display Unit"](#) .

>> GO TO 3.


3. SELF-DIAGNOSIS CHECK

1. Disconnect audio unit connector M53.
2. Perform self-diagnosis mode.

Can self-diagnosis mode be activated?

Yes >> GO TO 4.

No >> AV communication line check. Refer to [DI-137, "AV Communication Line Check"](#) .



LCD (LIQUID CRYSTAL DISPLAY)

4. MULTIFUNCTION SWITCH CIRCUIT CHECK

1. Disconnect multifunction switch connector.
2. Check continuity between multifunction switch and audio unit.


| Terminals | | | | Continuity |
|----------------------|--------------------------|------------|--------------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |

3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|--------------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

OK or NG

- OK >> GO TO 5.
 NG >> Replace harness or connector.



5. AUDIO UNIT CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.

| Terminals | | | | Continuity |
|------------|--------------------------|-----------------|--------------------------|------------|
| Audio unit | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R/G) | B31 | 28 (R/G) | Yes |
| | 21 (R/L) | | 29 (*1) | |
| | 22 (R/W) | | 30 (*2) | |

*1: Sedan and wagon models (W)
 Hatchback models (R/L)

*2: Sedan and wagon models (B)
 Hatchback models (R/W)

3. Check continuity between audio unit and ground.


| Terminals | | | Continuity |
|-----------|--------------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M52 | 20 (R/G) | Ground | No |
| | 21 (R/L) | | |
| | 22 (R/W) | | |

OK or NG

- OK >> Inspection end.
 NG >> Replace harness or connector.

RGB Screen Is Not Shown

Replace display unit.



A
B
C
D
E
F
G
H
I
J
DI
L
M

LCD (LIQUID CRYSTAL DISPLAY)

Color of RGB Image Is Not Proper

EKS009CE

Replace display unit.

RGB Screen Is Rolling

EKS009CF

Replace display unit.


Air Conditioning Controls (Only) Are Ineffective (Rear Defogger Control Excluded)

EKS009CG

1. A/C AUTO AMP. AND DISPLAY UNIT CIRCUIT CHECK


1. Turn the ignition switch OFF.
2. Disconnect A/C auto amp. connector and display unit connector.
3. Check continuity between display unit and A/C auto amp.

| Terminals | | | | Continuity |
|------------------|-----------------------|-------------------|-----------------------|------------|
| Display unit (+) | | A/C auto amp. (-) | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 13 (L) | M75 | 20 (L) | YES |
| | 14 (L/R) | | 10 (L/R) | |
| | 15 (L/W) | | 9 (L/W) | |



4. Check continuity between display unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|--------|------------|
| Connector | Terminal (wire color) | (-) | |
| M61 | 13 (L) | Ground | NO |
| | 14 (L/R) | | |
| | 15 (L/W) | | |




OK or NG

- OK >> GO TO 2.
 NG >> Replace harness or connector.

2. A/C-AV, AV-AC, AC-CLK COMMUNICATION SIGNAL CHECK

1. Connect A/C auto amp. connector.
2. Turn the ignition switch ON.
3. Check voltage between display unit and ground.

| Terminals | | | Voltage [V] |
|---------------------------|-----------------------|--------|---------------------|
| (+) Terminal (wire color) | | (-) | |
| Connector | Terminal (wire color) | (-) | |
| M61 | 13 (L) | Ground | Approx. 3.5 or more |
| | 14 (L/R) | | |
| | 15 (L/W) | | |



OK or NG

- OK >> GO TO 3.
 NG >> Replace A/C auto amp.

LCD (LIQUID CRYSTAL DISPLAY)


3. A/C- AV, AV- AC, AC- CLK COMMUNICATION SIGNAL CHECK

1. Connect display unit harness connector.
2. Turn the ignition switch ON.
3. Check voltage signal between display unit and ground with oscilloscope or CONSULT-II.

| Terminals | | (-) | Reference signal |
|-----------|-----------------------|--------|--|
| (+) | | | |
| Connector | Terminal (wire color) | | |
| M61 | 13 (L) | Ground | DI-121, "Terminals and Reference Value for Display Unit" |
| | 14 (L/R) | | |
| | 15 (L/W) | | |

OK or NG

- OK >> Replace A/C auto amp.
 NG >> Replace display unit.



Fuel Information Is Not Displayed/Warning Message Is Not Displayed/LHD Models

EKS009CH

1. COMMUNICATION LINE (MA-AV, AV-ME) CIRCUIT CHECK

1. Disconnect the display unit connector and combination meter connector.
2. Check continuity between display unit and ground.


| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (wire color) | Terminal | |
| M61 | 16 (R) | Ground | No |
| | 18 (G) | | |

3. Check continuity between display unit and combination meter.

| Terminals | | | | Continuity |
|--------------|-----------------------|-------------------|-----------------------|------------|
| Display unit | | Combination meter | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 16 (R) | M37 | 41 (R) | Yes |
| | 18 (G) | | 40 (G) | |

OK or NG


- OK >> GO TO 2.
 NG >> Replace harness or connector.




LCD (LIQUID CRYSTAL DISPLAY)

2. COMMUNICATION SIGNAL (AV-ME) CHECK

1. Connect display unit connector and combination meter connector.
2. Turn ignition switch ON.
3. Check voltage signal between display unit harness connector M61 terminal 16 (R) and ground with oscilloscope or CONSULT-II.



SKIA0169E




OK or NG

OK >> GO TO 3.


NG >> Replace display unit.

3. COMMUNICATION SIGNAL (ME-AV) CHECK

1. Turn ignition switch to ON and display.
2. Check voltage signal between display unit harness connector M61 terminal 18 (G) and ground with oscilloscope or CONSULT-II.



SKIA0170E



OK or NG

OK >> Replace display unit.

NG >> Replace combination meter.

LCD (LIQUID CRYSTAL DISPLAY)


Fuel Information Is Not Displayed/Warning Message Is Not Displayed/RHD Models

EKS009CI

1. COMMUNICATION LINE (MA-AV, AV-ME) CIRCUIT CHECK

1. Disconnect the display unit connector and combination meter connector.
2. Check continuity between display unit and combination meter.

| Terminals | | | | Continuity |
|--------------|-----------------------|-------------------|-----------------------|------------|
| Display unit | | Combination meter | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 16 (R) | M37 | 28 (R) | Yes |
| | 18 (G) | | 27 (G) | |



3. Check continuity between display unit and ground.


| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (wire color) | Terminal | |
| M61 | 16 (R) | Ground | No |
| | 18 (G) | | |

OK or NG


- OK >> GO TO 2.
 NG >> Replace harness or connector.

2. COMMUNICATION SIGNAL (AV-ME) CHECK

1. Connect display unit connector and combination meter connector.
2. Turn ignition switch ON.
3. Check voltage signal between display unit harness connector M61 terminal 16 (R) and ground with oscilloscope or CONSULT-II.



SKIA0169E




OK or NG

- OK >> GO TO 3.
 NG >> Replace display unit.


LCD (LIQUID CRYSTAL DISPLAY)

3. COMMUNICATION SIGNAL (ME-AV) CHECK

1. Turn ignition switch to ON and display.
2. Check voltage signal between display unit harness connector M61 terminal 18 (L) and ground with oscilloscope or CONSULT-II.



SKIA0170E



MKIB0698E

OK or NG

- OK >> Replace display unit.
- NG >> Replace combination meter.

Multifunction Switch Does Not Operate

EKS009CJ

1. POWER AND GROUND CIRCUIT CHECK

- Check power and ground circuit. Refer to [DI-123, "Terminals and Reference Value for Multifunction Switch"](#).


OK or NG

- OK >> Replace multifunction switch.
- NG >> Repair or replace harness.

Removal and Installation of Multifunction switch

EKS009CK

1. Remove the cluster lid C. Refer to IP section in P12 ESM (SM2E00-1P12E0E).
2. Remove the screw (4), and remove the multifunction switch.




MKIB0143E

Removal and Installation of Display Unit

EKS009CL

1. Remove the cluster lid C. Refer to IP section in P12 ESM (SM2E00-1P12E0E).
2. Remove the screws (2), and remove the display unit.



MKIB0047E