

# ALPHABETICAL INDEX

## SECTION **IDX**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

**IDX**

# ALPHABETICAL INDEX

## A

A/C air flow .....ATC-28  
A/C compressor clutch removal and  
installation .....ATC-138  
A/C compressor precaution.....ATC-7  
A/C compressor special service tool .....ATC-11  
A/C HFC134a (R134a) system  
precaution .....ATC-4  
A/C HFC134a (R134a) system service  
procedure.....ATC-132  
A/C HFC134a (R134a) system service  
tools.....ATC-11  
A/C HFC134a system service equip-  
ment precaution .....ATC-8  
A/C lubricant (R134a).....ATC-21  
A/C lubrication oil .....ATC-150  
A/C operational check .....ATC-56  
A/C performance test diagnoses.....ATC-89  
A/C rera .....ATC-86  
A/C self-diagnoses (auto A/C).....ATC-48  
A/C service data specification .....ATC-150  
A/C system description (auto A/C) .....ATC-23  
A/C trouble diagnoses (auto A/C) .....ATC-30  
A/C, A - Wiring diagram.....ATC-35  
A/T IND - Wiring diagram .....DI-99  
A/T indicator.....DI-99  
ABS - Wiring diagram.....BRC-13  
Accelerator control system .....ACC-2  
Accelerator pedal position (APP)  
sensor (YD) ..EC-124, EC-164, EC-250, EC-255,  
EC-298, EC-442, EC-478, EC-548,  
EC-553, EC-594  
Air bleeding (hydraulic clutch) (YD).....CL-8  
Air bleeding for brake system .....BR-10  
Air cleaner and air duct(YD22DDTi) .....EM-15  
Air cleaner and air duct .....EM-143  
Air cleaner filter replacement(YD).....MA-21  
Air cleaner filter(YD22DDTi) .....EM-15  
Air cleaner filter .....EM-144  
Air conditioner cut control (YD).....EC-25, EC-364  
Air mix door control linkage  
adjustment .....ATC-69, ATC-126  
Air mix. door motor.....ATC-67, ATC-126  
Alternator .....SC-12  
Ambient sensor.....ATC-100, ATC-102, ATC-115  
Angular tightening  
application(YD22DDTi).....EM-5  
Angular tightening application.....EM-126  
Antenna .....AV-36  
APP2PW - Wiring diagram (YD)....EC-257, EC-555  
APPS - Wiring diagram (YD) .....EC-126, EC-444  
APPS2 - Wiring diagram (YD) .....EC-166, EC-480  
APPS3 - Wiring diagram (YD) .....EC-300, EC-596  
ASC/BS - Wiring diagram (YD).....EC-226, EC-526  
ASC/SW - Wiring diagram (YD).....EC-237, EC-536  
ASCIND - Wiring diagram (YD) .....EC-344, EC-649  
AUDIO - Wiring diagram .....AV-9  
Audio .....AV-4

Auto air conditioner - Wiring diagram .....ATC-35  
Auto anti-dazzling inside mirror .....GW-14, GW-15  
Auto wiper .....WW-18  
Automatic amplifier.....ATC-45, ATC-59  
Automatic transmission fluid  
replacement.....MA-31  
AV and NAVI control unit .....AV-41  
AV communication line.....AV-62  
Axle .....MA-34

## B

Back door .....BL-114  
Back-up lamp switch (M/T) (YD) .....MT-12  
Back-up lamp.....LT-66, LT-92  
BACK/L - Wiring diagram .....LT-66  
Ball joint (front) .....FSU-10, FSU-13  
Barometric pressure (BARO) sensor  
(YD) .....EC-315, EC-611  
Basic inspection (YD) .....EC-44, EC-378  
Battery .....SC-3  
Baulk ring (M/T) (YD) .....MT-18  
Blower motor .....ATC-73, ATC-78, ATC-120  
Blower unit .....ATC-119  
Board-on lift .....GI-41  
BOOST - Wiring diagram (YD) .....EC-179, EC-492  
Bose speaker amp.....AV-4  
Brake booster .....BR-20  
Brake fluid change .....BR-9  
Brake fluid level and line check .....BR-9  
Brake fluid level .....MA-31  
Brake hydraulic line .....BR-11  
Brake inspection .....MA-32  
Brake lines and cables inspection .....MA-32  
Brake master cylinder .....BR-14  
Brake pedal .....BR-6  
Brake switch (YD) .....EC-324, EC-631  
BRK/SW - Wiring diagram (YD).....EC-325, EC-632  
Bulb specifications .....LT-147

## C

Camshaft inspection(YD22DDTi) .....EM-55  
Camshaft inspection.....EM-175, EM-224  
Camshaft position sensor (CMPS)  
(YD) .....EC-193, EC-199, EC-506, EC-512  
Camshaft(YD22DDTi) .....EM-54  
CAN (Controller Area Network).....LT-134, LAN-5,  
LAN-10, LAN-28,  
LAN-41, LAN-57,  
LAN-70, LAN-88,  
LAN-104, LAN-122,  
LAN-138, LAN-157,  
LAN-172, LAN-188

# ALPHABETICAL INDEX

CAN - Wiring diagram  
(YD).....EC-84, EC-417, LAN-11, LAN-29,  
LAN-42, LAN-58, LAN-71, LAN-89,  
LAN-105, LAN-123, LAN-139, LAN-158,  
LAN-173, LAN-189

CAN communication  
(YD) .....EC-26, EC-83, EC-365, EC-416, BRC-5,  
BRC-25, BRC-35, BRC-42, LT-134, LAN-5,  
LAN-10, LAN-28, LAN-41, LAN-57, LAN-70,  
LAN-88, LAN-104, LAN-122, LAN-138,  
LAN-157, LAN-172, LAN-188

CD/CHG - Wiring diagram .....AV-9

CHARGE - Wiring diagram .....SC-13

Charging system .....SC-12

Chassis and body maintenance .....MA-30

CHIME - Wiring diagram .....DI-103

CIGAR - Wiring diagram.....WW-59

Cigarette lighter .....WW-59

Circuit breaker.....PG-23

CKPS - Wiring diagram (YD).....EC-86, EC-184,  
EC-189, EC-419,  
EC-497, EC-502

Clearance lamp.....LT-89

CLOCK - Wiring diagram.....DI-122

Clock .....DI-122

Clutch cover (F9Q) .....CL-14

Clutch cover (YD) .....CL-15

Clutch disc (F9Q).....CL-14

Clutch disc (YD).....CL-15

Clutch master cylinder (F9Q) .....CL-9

Clutch master cylinder (YD) .....CL-9

Clutch operating cylinder (YD).....CL-11

Clutch pedal (F9Q) .....CL-7

Clutch pedal (YD) .....CL-5

Clutch release bearing (F9Q) .....CL-13

Clutch release bearing (YD) .....CL-13

Clutch release mechanism (F9Q).....CL-13

Clutch release mechanism (YD).....CL-13

Clutch withdrawal lever (F9Q) .....CL-13

Clutch withdrawal lever (YD) .....CL-13

CMPS - Wiring diagram (YD) .....EC-86, EC-195,  
EC-201, EC-419,  
EC-508, EC-514

Coil spring (front) .....FSU-8

Coil spring (rear).....RSU-8

Combination meter .....DI-4, DI-27

Combination switch .....LT-60, LT-94

COMM - Wiring diagram .....DI-57, AV-62

Component Location (auto A/C).....ATC-31

Compression pressure(YD22DDTi) .....EM-78

Compressor clutch removal and  
installation .....ATC-138

Compressor special service tool .....ATC-11

Condenser .....ATC-144

Connecting rod bearing  
clearance(YD22DDTi) .....EM-111

Connecting rod bushing  
clearance(YD22DDTi) .....EM-106

Connecting rod(YD22DDTi) .....EM-103, EM-107

Connecting rod.....EM-226

CONSULT general information.....GI-34

CONSULT-II for engine (YD) .....EC-64, EC-397

Control unit .....ATC-113

Control units (terminal arrangement) .....PG-110

Controller Area Network  
(CAN) .....LT-134, LAN-5, LAN-10, LAN-28,  
LAN-41, LAN-57, LAN-70, LAN-88,  
LAN-104, LAN-122, LAN-138, LAN-157,  
LAN-172, LAN-188

COOL/F - Wiring diagram (YD) .....EC-150, EC-466

Coolant mixture ratio.....MA-16

Coolant replacement(YD).....MA-17, MA-25

Cooling circuit (engine)(YD).....CO-7

Cooling fan motor (YD) .....EC-163, EC-477

Cooling fan relay (YD) .....EC-163, EC-477

Cooling fan(YD).....CO-11

Cooling fan.....CO-28

Coupling sleeve (M/T) (YD) .....MT-18

Crankcase ventilation system (YD)..EC-26, EC-365

Crankshaft position sensor (TDC)  
(YD) .....EC-182, EC-187, EC-495, EC-500

Crankshaft(YD22DDTi) .....EM-105

Crankshaft.....EM-227

Cylinder block boring(YD22DDTi).....EM-109

Cylinder block(YD22DDTi) .....EM-93

Cylinder head bolt  
tightening(YD22DDTi) .....EM-80

Cylinder head bolt tightening .....EM-220

Cylinder head gasket  
selection(YD22DDTi).....EM-80

Cylinder head(YD22DDTi) .....EM-78

Cylinder head .....EM-161, EM-171, EM-176

## D

Data link connector for Consult  
(YD) .....EC-64, EC-397

Daytime light system .....LT-18, LT-27

Daytime running light - See Daytime  
light system.....LT-18, LT-27

DEF - Wiring diagram .....GW-22

Diagnostic trouble code (DTC) (YD).....EC-370

Diagnostic trouble code (DTC) for OBD  
system (YD) .....EC-11, EC-33, EC-351

Diagnostic trouble code (DTC) inspec-  
tion priority chart (YD).....EC-43, EC-377

Differential gear (FF M/T) (YD) .....MT-21

Dimensions .....GI-47

Door glass Fitting Adjustment.....GW-64, GW-68

Door glass.....GW-64, GW-68

Door lock .....BL-107, BL-109

Door, front .....BL-10

Door, rear .....BL-10

Drive belt inspection(YD) .....MA-17

Drive belt(YD22DDTi) .....EM-13

Drive belt.....EM-142

Drive shaft (front) .....FAX-11

DTRL - Wiring diagram.....LT-20, LT-29

Dual pressure switch.....ATC-15, ATC-87, ATC-144

Duct and grilles.....ATC-130

## ALPHABETICAL INDEX

### E

ECM power supply (YD) .....EC-76, EC-409  
ECM relay (YD).....EC-260, EC-558  
ECTS - Wiring diagram (YD) .....EC-121, EC-439  
EGR function (YD).....EC-209, EC-620  
EGR volume control valve (YD).....EC-209, EC-620  
EGRC/V - Wiring diagram (YD).....EC-212, EC-622  
Electrical diagnoses.....GI-10  
Electrical unit .....PG-110  
Electrical units location .....PG-101  
Engine control circuit diagram  
(YD) .....EC-55, EC-389  
Engine control module (ECM)  
(YD) .....EC-241, EC-243, EC-539, EC-541  
Engine control system diagram and  
chart (YD) .....EC-21, EC-360  
Engine coolant temperature sensor  
(ECTS) (YD) .....EC-119, EC-437  
Engine coolant(YD) .....CO-8  
Engine coolant .....CO-25  
Engine oil filter replacement(YD) .....MA-22  
Engine oil precautions .....GI-7  
Engine oil replacement(YD) .....MA-21  
Engine oil(YD).....LU-5  
Engine oil .....LU-16  
Engine removal(YD22DDTi).....EM-89  
Engine removal .....EM-164  
Engine room cover.....EM-141  
Evaporator .....ATC-145  
Exhaust manifold(YD22DDTi) .....EM-23  
Exhaust manifold .....EM-146  
Exhaust system inspection .....EX-2, MA-30  
Exhaust system .....EX-2  
Expansion valve .....ATC-145

### F

F/FOG - Wiring diagram .....LT-81  
F/PUMP - Wiring diagram  
(YD) .....EC-279, EC-285, EC-290, EC-576,  
EC-581, EC-586, EC-591  
Fan control amp. ....ATC-75, ATC-127  
FIAR - Wiring diagram (YD).....EC-268, EC-565  
Final drive (FF M/T) (YD).....MT-21, MT-55  
Flow charts .....GI-24  
Fluids.....MA-15  
Fluorescent leak detector .....ATC-146  
Flywheel (clutch) (F9Q) .....CL-14  
Flywheel (clutch) (YD) .....CL-15  
Flywheel runout(YD22DDTi) .....EM-113  
Fog lamp, front .....LT-80  
Fog lamp, rear .....LT-84  
Fork rod (M/T) (YD).....MT-59  
Freeze frame data (YD).....EC-34, EC-370  
Front disc brake .....BR-23  
Front door .....BL-10  
Front fog lamp .....LT-80

Front suspension.....FSU-5  
FRONT.....WW-18  
FRPS - Wiring diagram (YD) .....EC-136, EC-454  
FTS - Wiring diagram (YD).....EC-131, EC-449  
Fuel cut control (at no load high engine  
speed) (YD) .....EC-25, EC-364  
Fuel filler lid.....BL-122  
Fuel filter (YD).....EC-29, EC-368  
Fuel filter replacement(YD).....MA-20  
Fuel filter replacement.....FL-4, FL-6  
Fuel gauge .....FL-8, FL-11, DI-4, DI-27  
Fuel injection control system (YD)...EC-23, EC-362  
Fuel injector adjustment resistor  
(YD) .....EC-266, EC-563  
Fuel injector and fuel tube(YD22DDTi).....EM-39  
Fuel line inspection(YD).....MA-20  
Fuel line inspection .....FL-3  
Fuel precautions .....GI-5  
Fuel pump (YD)..EC-29, EC-245, EC-277, EC-283,  
EC-293, EC-368, EC-543, EC-574,  
EC-579, EC-584, EC-589  
Fuel rail pressure sensor (YD).....EC-134, EC-452  
Fuel system .....FL-3  
Fuel tank .....FL-14, FL-17  
Fuel temperature sensor (YD) .....EC-130, EC-448  
Fuse and fusible link box .....PG-114  
Fuse .....PG-23  
Fusible link .....PG-23

### G

Garage jack and safety stand .....GI-39  
Gear components (M/T) (YD) .....MT-18  
Generator - See Alternator .....SC-12  
Generator .....SC-12  
Generic scan tool (GST) (YD).....EC-70  
Glass.....GW-64, GW-68  
GLOW - Wiring diagram  
(YD).....EC-206, EC-318, EC-614  
Glow plug(YD22DDTi).....EM-34  
Glow plug .....EM-153, EC-317, EC-613  
Glow relay (YD) .....EC-205, EC-317, EC-613  
GPS antenna.....AV-40  
Grease .....MA-15  
Ground distribution.....PG-24

### H

H/AIM - Wiring diagram.....LT-35, LT-38  
H/LAMP - Wiring diagram .....LT-6, LT-12  
H/MIRROR - Wiring diagram .....GW-22  
Harness connector .....PG-108  
Harness layout .....PG-44  
Hazard warning lamp.....LT-46  
Headlamp aiming control.....LT-35, LT-37  
Headlamp leveler - See Headlamp  
aiming control .....LT-35, LT-37  
Headlamp washer.....WW-53

# ALPHABETICAL INDEX

Headlamp .....LT-5, LT-10  
 Heater and cooling unit (Heater core).....ATC-122  
 Heater mirror .....GW-22  
 Heater unit (heater core) .....ATC-129  
 Height (Dimensions) .....GI-47  
 HFC134a (R134a) system precaution.....ATC-4  
 HFC134a (R134a) system service  
     procedure.....ATC-132  
 HFC134a (R134a) system service tools .....ATC-11  
 HFC134a system service equipment  
     precaution .....ATC-8  
 HLC - Wiring diagram.....WW-54  
 HORN - Wiring diagram .....WW-57  
 Horn .....WW-57  
 How to erase DTC (YD).....EC-370  
 How to erase DTC for OBD system  
     (YD).....EC-34

## I

I/MIRR - Wiring diagram .....GW-14  
 IATS - Wiring diagram (YD) .....EC-116, EC-434  
 Identification plate.....GI-47  
 Identification.....ATC-10  
 Idle speed (YD).....EC-44, EC-378  
 ILL - Wiring diagram .....LT-99  
 Illumination.....LT-97  
 In vehicle sensor .....ATC-102, ATC-104, ATC-116  
 INJE/PW - Wiring diagram (YD) ....EC-307, EC-603  
 INJECT - Wiring diagram (YD) ....EC-144, EC-274,  
     EC-312, EC-461,  
     EC-571, EC-608  
 Injection nozzle(YD22DDTi).....EM-39  
 Input shaft (FF M/T) (YD) .....MT-18, MT-37  
 INT/L - Wiring diagram .....LT-130  
 Intake air temperature sensor  
     (YD) .....EC-115, EC-433  
 Intake door control linkage adjustment .....ATC-71  
 Intake door motor .....ATC-70, ATC-121  
 Intake manifold(YD22DDTi) .....EM-19  
 Intake manifold.....EM-146  
 Intake sensor .....ATC-108, ATC-118  
 Interior lamp on-off control .....LT-110, LT-111  
 Interior lamp .....LT-110  
 ISO 15031-2 Terminology .....GI-49  
 ISO 15031-5 Mode 1 - 9 (YD) .....EC-31

## K

Key illumination.....LT-110  
 Keyless entry system - See Multi-re-  
     mote control system.....BL-79  
 Knuckle spindle .....FAX-7

## L

LAN system circuit.....ATC-61

LCD display .....DI-50  
 Length (Dimensions) .....GI-47  
 License lamp.....LT-70  
 Liquid gasket  
     application(QR20DE-QR25DE) .....EM-127  
 Liquid gasket application(YD22DDTi) .....EM-6  
 Location of electrical units .....PG-101  
 Lock, door .....BL-107, BL-109  
 Lubricant (R134a) A/C.....ATC-5, ATC-21  
 Lubricants.....MA-15  
 Lubrication circuit (engine)(YD) .....LU-4  
 Lubrication oil A/C .....ATC-150  
 Lubrication-locks, hinges and hood  
     latches .....MA-34  
 Luggage room lamp.....LT-130

## M

M/T oil replacement (YD) .....MT-10  
 M/T removal and installation (YD).....MT-15  
 MAFS - Wiring diagram  
     (YD) .....EC-105, EC-112, EC-430  
 Magnet clutch .....ATC-79, ATC-138  
 MAIN - Wiring diagram (YD).....EC-77, EC-410  
 Main drive gear (M/T) (YD) .....MT-18  
 Mainshaft (M/T) (YD) .....MT-18, MT-44  
 Malfunction indicator (MI) (YD).....EC-36, EC-371  
 Mass air flow sensor (MAFS)  
     (YD) .....EC-102, EC-110, EC-428  
 Master cylinder (brake) .....BR-14  
 Master cylinder (clutch) (F9Q) .....CL-9  
 Master cylinder (clutch) (YD) .....CL-9  
 METER - Wiring diagram.....DI-13, DI-36  
 MIL/DL - Wiring diagram (YD) .....EC-347, EC-652  
 MIRROR - Wiring diagram .....GW-71  
 Mirror defogger.....GW-22  
 Mode door control linkage  
     adjustment .....ATC-66, ATC-125  
 Mode door motor.....ATC-64, ATC-125  
 Model variation .....GI-45  
 Molding - See Exterior.....GW-4, GW-8  
 MULTI - Wiring diagram.....BL-83  
 Multi-remote control system.....BL-79  
 Multiport fuel injection precautions.....GI-6

## N

NATS (Nissan anti-theft system)  
     precautions .....GI-3  
 NATS (Nissan anti-theft system).....BL-151  
 NATS - Wiring diagram .....BL-154  
 NAVI - Wiring diagram .....AV-54  
 Navigation system.....AV-39  
 NVH troubleshooting (BR).....BR-5  
 NVH troubleshooting (CL) (F9Q) .....CL-4  
 NVH troubleshooting (EM).....EM-130  
 NVH troubleshooting (RSU) .....RSU-4



## ALPHABETICAL INDEX

NVH troubleshooting (ST) .....PS-4

### O

Oil cooler (engine)(YD) .....LU-12  
Oil cooler (engine) .....LU-20  
Oil filter(YD) .....LU-7  
Oil filter .....LU-18  
Oil pan (engine)(YD22DDTi) .....EM-29  
Oil pan (engine) .....EM-150  
Oil pressure (engine)(YD) .....LU-5  
Oil pump (engine)(YD) .....LU-10  
Oil pump (engine) .....LU-19  
Oil pump regulator valve (engine)(YD) .....LU-11  
On board diagnostic system (YD) .....EC-31  
Operating cylinder (clutch) (YD) .....CL-11  
Overheat (YD) .....EC-147, EC-464  
Oversize piston(YD22DDTi) .....EM-109

### P

Park/neutral position switch (M/T)  
(YD) .....MT-12  
Park/Neutral position switch (YD) ..EC-332, EC-638  
Parking lamp .....LT-70  
Piston assembly .....EM-224  
Piston pin inspection(YD22DDTi) .....EM-102  
Piston ring inspection(YD22DDTi) .....EM-106  
Piston ring inspection .....EM-225  
Piston to bore clearance(YD22DDTi) .....EM-109  
PNP/SW - Wiring diagram (YD) ....EC-333, EC-639  
POWER - Wiring diagram .....PG-5  
Power door lock .....BL-13  
Power steering fluid level .....PS-5, PS-19, MA-33  
Power steering gear .....PS-12, PS-19  
Power steering hydraulic pressure .....PS-16  
Power steering oil pressure switch  
(YD) .....EC-336, EC-642  
Power steering oil pump .....PS-16, PS-19  
Power steering system bleeding .....PS-5  
Power supply routing .....PG-3  
Power window .....GW-38  
Precations for Leak detection dye .....ATC-10  
Precautions (General) .....GI-4  
Pressure plate - See Clutch cover  
(F9Q) .....CL-14  
Pressure plate - See Clutch cover (YD) .....CL-15  
PST/SW - Wiring diagram (YD) ....EC-337, EC-643

### Q

Quick-glow system (YD) .....EC-317, EC-613

### R

R/FOG - Wiring diagram .....LT-84  
R/VIEW - Wiring diagram .....DI-126  
Radiator fan - See Cooling fan(YD) .....CO-11  
Radiator fan - See Cooling fan .....CO-28  
Radiator(YD) .....CO-10  
Radiator .....CO-27  
Radio - See Audio .....AV-4  
Rain sensor .....WW-18  
Rear disc brake .....BR-28  
Rear door .....BL-10  
Rear fog lamp .....LT-84, LT-92  
Rear side window .....GW-6  
Rear suspension .....RSU-5  
Rear view camera .....DI-123  
Rear view monitor .....DI-123  
Rear washer .....WW-39  
Rear window defogger .....GW-16  
Rear wiper .....WW-39  
Refrigerant connection precaution .....ATC-5  
Refrigerant discharging evacuating  
charging .....ATC-132  
Refrigerant general precaution .....ATC-4  
Refrigerant lines .....ATC-132  
Refrigerant pressure  
sensor .....ATC-15, ATC-86, ATC-144  
Refrigeration cycle .....ATC-15  
Release bearing (clutch) (F9Q) .....CL-13  
Release bearing (clutch) (YD) .....CL-13  
Reverse idler shaft (M/T) (YD) .....MT-18, MT-53  
Reverse lamp switch (M/T) - See  
Back-up lamp switch (M/T) (YD) .....MT-12  
Reverse main gear (M/T) (YD) .....MT-18  
Road wheel size .....GI-48  
Rocker cover(YD22DDTi) .....EM-52  
Rocker cover .....EM-155  
Room lamp - See Interior lamp .....LT-110  
Room lamp .....LT-110  
ROOM/L - Wiring diagram .....LT-113

### S

S/LOCK - Wiring diagram .....BL-16, BL-44  
S/SIG - Wiring diagram (YD) .....EC-340, EC-646  
SCTC/V - Wiring diagram  
(YD) .....EC-247, EC-295, EC-545  
Seat belt inspection .....MA-35  
Sheft warning system .....BL-123  
Shift control components (M/T) (YD) .....MT-20  
Shift fork (M/T) (YD) .....MT-59  
Shift lever (YD) .....MT-13  
Shock absorber (front) .....FSU-8  
Shock absorber (rear) .....RSU-8  
Side window - See Rear side window .....GW-6  
Spare tire size .....GI-48  
Speedometer .....DI-4, DI-27  
Spot lamp .....LT-130

# ALPHABETICAL INDEX

Spring (Wheelarch) height .....FSU-15, RSU-12  
 Stabilizer bar (front).....FSU-11  
 Stabilizer bar (rear) .....RSU-11  
 Standardized relay.....PG-111  
 START - Wiring diagram.....SC-21, SC-22  
 Start signal (YD) .....EC-340, EC-646  
 Starter.....SC-20  
 Starting system.....SC-20  
 Steering gear and linkage inspection .....MA-33  
 Steering knuckle .....FAX-7  
 Steering linkage.....PS-12, PS-18  
 Steering wheel and column .....PS-6, PS-9, PS-18  
 Steering wheel play .....PS-6  
 Steering wheel turning force .....PS-6  
 Step lamp .....LT-110  
 Stop lamp .....LT-62, LT-92  
 STOP/L - Wiring diagram .....LT-62  
 Striking rod (M/T) (YD).....MT-20  
 Strut (front) (YD) .....CL-5, FSU-8  
 Suction control valve (YD) .....EC-288  
 Sunload sensor.....ATC-105, ATC-107, ATC-117  
 Super lock .....BL-42  
 Suspension .....MA-34  
 Symbols and abbreviations .....GI-10, GI-22  
 Synchronizer (M/T) (YD) .....MT-18

## T

Tachometer .....DI-4, DI-27  
 Tail lamp .....LT-70, LT-89, LT-92  
 TAIL/L - Wiring diagram.....LT-70  
 TC boost control solnoid valve  
 (YD) .....EC-88, EC-627  
 TC boost sensor (YD).....EC-177, EC-490  
 TCC/V - Wiring diagram (YD).....EC-90, EC-628  
 THEFT - Wiring diagram.....BL-128  
 Thermostat(YD).....CO-20  
 Three way catalyst precautions.....GI-5  
 Throwout bearing - See Clutch release  
 bearing (F9Q).....CL-13  
 Throwout bearing - See Clutch release  
 bearing (YD).....CL-13  
 Tightening torque of standard bolts.....GI-44  
 Timing belt.....EM-157  
 Timing chain(YD2DDTi).....EM-63, EM-68  
 Tire size .....GI-48  
 Tow truck towing.....GI-42  
 Transmission case (M/T) (YD) .....MT-17  
 Tread-FR&RR (Dimensions).....GI-47  
 Trouble diagnoses .....GI-10  
 Trunk lid .....BL-111  
 Trunk room lamp .....LT-130  
 Turbocharger charge air  
 cooler(YD2DDTi) .....EM-17  
 Turbocharger charge air cooler .....EM-145  
 Turbocharger precautions.....GI-6  
 Turbocharger(YD2DDTi) .....EM-23  
 Turbocharger.....EM-146  
 TURN - Wiring diagram.....LT-50  
 Turn signal lamp .....LT-46, LT-92

Two-pole lift .....GI-40  
 Tyre pressure monitoring system -  
 trouble diagnoses .....WT-16  
 Tyre pressure monitoring system -  
 wiring diagram .....WT-16  
 Tyre pressure monitoring system .....WT-8

## V

Vacuum hose (brake system).....BR-22  
 Vacuum pump(YD2DDTi).....EM-35  
 Vacuum pump .....EM-154  
 Valve clearance(YD2DDTi) .....EM-59  
 Valve clearance .....EM-175, EM-223  
 Valve guide(YD2DDTi) .....EM-85  
 Valve guide.....EM-222  
 Valve lifter(YD2DDTi) .....EM-57  
 Valve seat(YD2DDTi) .....EM-86  
 Valve seat.....EM-221  
 Valve spring(YD2DDTi) .....EM-88  
 Valve spring.....EM-223  
 Vanity mirror lamp.....LT-130  
 Vehicle identification number.....GI-46  
 Vehicle recovery (freeing a stuck  
 vehicle).....GI-43  
 Ventilation air filter .....ATC-128  
 Viscosity number (SAE) .....MA-16

## W

WARN - Wiring diagram .....DI-85  
 Warning chime .....DI-101  
 Warning lamps .....DI-84  
 Washer, front .....WW-18  
 Washer, rear .....WW-39  
 Water pump(YD) .....CO-17  
 Water pump.....CO-30  
 Water temperature gauge.....DI-4, DI-27  
 Weatherstrip - See Exterior .....BL-12  
 Wheel alignment (front) .....FSU-6, FSU-15  
 Wheel alignment (rear) .....RSU-5, RSU-12  
 Wheel balance .....MA-31  
 Wheel bearing (front axle).....FAX-7  
 Wheel bearing (rear) .....RAX-5, RAX-8  
 Wheel hub (front).....FAX-7  
 Wheel hub (rear) .....RAX-5  
 Wheel sensors (ABS) .....BRC-30  
 Wheel size .....GI-48  
 Wheelarch height .....FSU-15, RSU-12  
 Wheelbase (Dimensions) .....GI-47  
 Width (Dimensions) .....GI-47  
 WINDOW - Wiring diagram.....GW-42  
 Window antenna .....AV-36  
 Window, door .....GW-64, GW-68  
 Window, rear side.....GW-6  
 Window, side - See Rear side window .....GW-6  
 Windshield .....GW-4, GW-8  
 WIP/R - Wiring diagram.....WW-41

## ALPHABETICAL INDEX

---

WIPER - Wiring diagram .....WW-6, WW-20  
Wiper and washer .....WW-18, WW-39  
Wiper, front .....WW-18  
Wiper, rear .....WW-39  
Wiring Diagram (Cell code) list .....PG-96

Wiring diagrams.....GI-14  
Withdrawal lever (clutch) (F9Q).....CL-13  
Withdrawal lever (clutch) (YD).....CL-13  
WT-T/WARN - Wiring diagram.....WT-16