

SECTION **LT**
LIGHTING SYSTEM

CONTENTS

PRECAUTION	4	HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -	18
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	System Description	18
Precaution	4	DESCRIPTION	18
Wiring Diagrams and Trouble Diagnosis	4	HEADLAMP OPERATION (DAYTIME CANCEL OPERATION)	18
HEADLAMP - CONVENTIONAL TYPE -	5	DAYTIME LIGHT OPERATION	18
System Description	5	Schematic	19
DESCRIPTION	5	Wiring Diagram — DTRL —	20
LOW BEAM OPERATION	5	Terminal and Reference Value for Daytime Light Control Unit	23
HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION	5	Trouble Diagnoses	23
Wiring Diagram — H/LAMP —	6	Aiming Adjustment	25
Trouble Diagnoses	7	Bulb Replacement	25
Aiming Adjustment	7	HEADLAMP	25
LOW BEAM	8	CLEARANCE LAMP, FRONT TURN SIGNAL LAMP	25
Bulb Replacement	9	HEADLAMP (WITH DAYTIME) - XENON TYPE - ...	26
HEADLAMP	9	System Description	26
CLEARANCE LAMP, FRONT TURN SIGNAL LAMP	9	Schematic	27
Removal and Installation	9	Wiring Diagram - DTRL -	28
REMOVAL	9	Terminal and Reference Value for Daytime Light Control Unit	31
INSTALLATION	9	Trouble Diagnoses	31
HEADLAMP - XENON TYPE -	10	DAYTIME LIGHT UNIT INSPECTION TABLE	31
System Description	10	Bulb Replacement	32
LOW BEAM OPERATION	10	Aiming Adjustment	32
HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION	10	HEADLAMP AIMING CONTROL (MANUAL)	33
Wiring Diagram - H/LAMP -	12	Wiring Diagram — H/AIM —	33
Trouble Diagnosis	14	Removal and Installation	34
Aiming Adjustment	15	Switch Circuit Inspection	34
LOW BEAM	15	HEADLAMP AIMING CONTROL (AUTO)	35
Bulb Replacement	16	System Description	35
XENON BULB (LOW BEAM)	16	Component Parts and Harness	35
HIGH BEAM	17	CONNECTOR LOCATION	35
CLEARANCE LAMP, FRONT TURN SIGNAL LAMP	17	Wiring Diagram - H/AIM -	36
Removal and Installation	17	CONSULT-II	38
REMOVAL	17	CONSULT-II INSPECTION PROCEDURE	38
INSTALLATION	17	CONSULT-II DIAGNOSTIC TEST MODE FUNCTION	38

INITIALIZATION	39	LICENSE PLATE LAMP	76
SELF-DIAGNOSTIC RESULTS ITEM CHART ...	39	Removal and Installation	76
Check Power and Ground for Height Sensor	40	PARKING AND TAIL LAMPS	76
Check Lighting Switch Circuit	40	LICENSE PLATE LAMP	76
Check Speed Signal Circuit	41	FRONT FOG LAMP	78
Check Headlamp Aiming Motor	42	System Description	78
Removal and installation	43	DESCRIPTION	78
TURN SIGNAL AND HAZARD WARNING LAMPS..	44	FOG LAMP OPERATION	78
System Description	44	Wiring Diagram — F/FOG —	79
TURN SIGNAL OPERATION	44	Aiming Adjustment	80
HAZARD LAMP OPERATION	45	Bulb Replacement	80
TURN SIGNAL (HAZARD) SOUND OPERATION	45	Removal and Installation	80
MULTI-REMOTE CONTROL SYSTEM OPERATION	46	REMOVAL	80
Schematic	47	INSTALLATION	81
Wiring Diagram — TURN —	48	REAR FOG LAMP	82
Terminal and Reference Valve for Smart Entrance Control Unit	51	Wiring Diagram — R/FOG — /Without Front Fog Lamp	82
Turn Signal And Hazard Warning Lamp Do Not Operate	51	Wiring Diagram — R/FOG — /With Front Fog Lamp..	84
Turn Signal Lamps Do Not Operate But Hazard Warning Lamp Operates	52	Bulb Replacement (Sedan and Hatchback)	86
Hazard Warning Lamps Do Not Operate But Turn Signal Lamp Operate	53	Bulb Replacement (Wagon)	86
Turn Signal Lamp LH Does Not Operate	54	Removal and Installation	86
Turn Signal Lamp RH Does Not Operate	55	REMOVAL (SEDAN AND HATCHBACK)	86
RH and LH Turn Indicators Do Not Operate	56	INSTALLATION (SEDAN AND HATCHBACK)	86
Bulb Replacement	57	CLEARANCE LAMP/TAIL LAMP	87
FRONT TURN SIGNAL LAMP	57	Bulb Replacement (Clearance Lamp)	87
SIDE TURN SIGNAL LAMP	57	Bulb Replacement (Tail Lamp)	87
REAR TURN SIGNAL LAMP	57	Removal and Installation of Clearance Lamp	87
Removal and Installation for Side Turn Signal Lamp..	57	Removal and Installation of Tail Lamp	87
Removal and Installation for Rear Turn Signal Lamp..	57	HIGH-MOUNTED STOP LAMP	88
LIGHTING AND TURN SIGNAL SWITCH	58	Bulb Replacement	88
Removal and Installation	58	HIGH-MOUNTED STOP LAMP (SEDAN)	88
Switch Circuit Inspection	58	HIGH-MOUNTED STOP LAMP (WAGON)	88
HAZARD SWITCH	59	HIGH-MOUNTED STOP LAMP (HATCHBACK)..	88
Removal and Installation	59	Removal and Installation	88
REMOVAL	59	HIGH-MOUNTED STOP LAMP (SEDAN)	88
INSTALLATION	59	HIGH-MOUNTED STOP LAMP (WAGON)	88
STOP LAMP	60	HIGH-MOUNTED STOP LAMP (HATCHBACK)..	89
Wiring Diagram — STOP/L —	60	REAR COMBINATION LAMP	90
Bulb Replacement	63	Bulb Replacement (Sedan)	90
STOP LAMP	63	Bulb Replacement (Wagon)	90
Removal and Installation	63	Bulb Replacement (Hatchback)	90
STOP LAMP	63	Removal and Installation	91
BACK-UP LAMP	64	REMOVAL (SEDAN)	91
Wiring Diagram — BACK/L —	64	REMOVAL (WAGON)	91
Bulb Replacement (Sedan and Hatch Back)	66	REMOVAL (HATCHBACK)	91
Bulb Replacement (Wagon)	66	INSTALLATION	91
Removal and Installation (Sedan and Hatch Back)..	66	COMBINATION SWITCH	92
Removal and Installation (Wagon)	66	Removal and Installation	92
PARKING, LICENSE PLATE AND TAIL LAMPS	67	Switch Circuit Inspection	93
Schematic	67	ILLUMINATION	95
Wiring Diagram - TAIL/L -/LHD MODELS	68	System Description	95
Wiring Diagram - TAIL/L -/RHD MODELS	72	Schematic	96
Bulb Replacement	76	Wiring Diagram — ILL —	97
PARKING AND TAIL LAMPS	76	INTERIOR ROOM LAMP	102
		System Description	102
		POWER SUPPLY AND GROUND	102
		SWITCH OPERATION	102
		INTERIOR ROOM LAMP TIMER OPERATION.	103
		ON-OFF CONTROL	103

Schematic	104
Wiring Diagram — ROOM/L —/LHD MODELS ...	105
Wiring Diagram — ROOM/L —/RHD MODELS ..	108
Terminal and Reference Valve for Smart Entrance	
Control Unit	111
CONSULT-II Inspection Procedure	111
“ROOM LAMP”	111
CONSULT-II Application Items	112
ROOM LAMP	112
Interior Room Lamp Timer Does Not Operate	113
Interior Room Lamp Timer Does Not Cancel	118
Bulb Replacement	121
INTERIOR ROOM LAMP	121
STEP LAMP	121
ASHTRAY	121
Removal and Installation	121
INTERIOR ROOM LAMP	121
STEP LAMP	121
ASHTRAY	121
SPOT, VANITY MIRROR AND TRUNK (LUGGAGE)	
ROOM LAMPS	122
Wiring Diagram — INT/L —	122
Bulb Replacement	124

SPOT LAMP	124
TRUNK ROOM LAMP	124
LUGGAGE ROOM LAMP	124
Removal and Installation	124
SPOT LAMP	124
TRUNK ROOM LAMP	124
LUGGAGE ROOM LAMP	125
CAN COMMUNICATION	126
System Description	126
CAN Communication Unit	126
TYPE 1/TYPE 8	127
TYPE 2/TYPE 9	129
TYPE 3/TYPE 10	130
TYPE 4/TYPE 11	132
TYPE 5,TYPE 17/TYPE 12,TYPE 20	133
TYPE 6,TYPE 7/TYPE 13,TYPE 14	134
TYPE 15/TYPE 18	135
TYPE 16/TYPE 19	137
BULB SPECIFICATIONS	139
Headlamp	139
Exterior Lamp	139
Interior Lamp/Illumination	139

A

B

C

D

E

F

G

H

I

J

LT

L

M

PRECAUTION

PFP:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS003T7

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precaution

EKS003T8

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of the headlamp. When replacing the bulb, be sure to replace it with a new one.
- Adjust aiming by tightening aiming screw. (To adjust it toward loosening side, first loosen adjusting screw, and then make adjustment by tightening.)
- To remove soil or sealant of bulbs, do not use organic solvent (thinner, gasoline, etc.)
- When replacing bulb, be sure to hold bulb socket and pull it out straight. If wiring harness of the bulb is pulled at an angle, the bulb may be caught in the lamp, making it difficult to take out.

Wiring Diagrams and Trouble Diagnosis

EKS003T9

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

HEADLAMP -CONVENTIONAL TYPE-

HEADLAMP -CONVENTIONAL TYPE-

PDF:26010

System Description DESCRIPTION

EKS004P6

The headlamps are controlled by the lighting switch which is built into the combination switch.
Power is supplied at all times

- to lighting switch terminal 8
- through 15A fuse (No. 41, located in the fuse and fusible link box), and
- to lighting switch terminal 5
- through 15A fuse (No. 42, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 5 of the headlamp LH, and
- from lighting switch terminal 7
- to terminal 5 of the headlamp RH.

Terminal 3 of each headlamp supplies ground through body grounds E10 and E58.
With power and ground supplied, the low beams will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal 9
- to terminal 4 of headlamp LH, and
- to combination meter terminal 20 (LHD models) or 7 (RHD models) for the HIGH BEAM indicator.
- from lighting switch terminal 6
- to terminal 4 of headlamp RH.

Ground is supplied to terminal 21 (LHD models) or 8 (RHD models) of the combination meter through body grounds M16, M50 and M70 (Gasoline engine models) or through body grounds M16, M50, M70 and F115.
Ground is supplied to terminal 3 of each headlamp through body grounds E10 and E58.
With power and ground supplied, the high beams and the HIGH BEAM indicator illuminate.

A

B

C

D

E

F

G

H

I

J







LT

L

M

Wiring Diagram — H/LAMP —

EKS004P7



HEADLAMP -CONVENTIONAL TYPE-

Trouble Diagnoses

EKS004P8

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 (R/W) of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 (R) of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 9 (BR/R) and LH headlamp terminal 4 (BR/R) for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 10 (R/Y) and LH headlamp terminal 5 (R/Y) for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 6 (Y) and RH headlamp terminal 4 (Y) for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 7 (PU) and RH headlamp terminal 5 (PU) for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) LHD or 7 (BR/R) RHD for an open circuit.

Aiming Adjustment

EKS004P9

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).


HEADLAMP -CONVENTIONAL TYPE-

CAUTION:


Be sure aiming switch is set to "0" when performing aiming adjustment.

LOW BEAM

- Turn headlamp low beam on.
LHD models



RHD models



- Use adjusting pots to perform aiming adjustment.

- First tighten the adjusting pot all the way and then make adjustment by loosening the pot.

If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines to point P in illustration show center of headlamp.

"H" : Horizontal center line of headlamps

"WL" : Distance between each headlamp center


"L" : 25 m (98.43 in)

"C" : 250 mm (9.84 in)

- Basic illuminating area for adjustment should be within the range shown in the figure. Adjust headlamps accordingly.

CAUTION:

Be sure aiming switch is set to "0" when performing aiming adjustment.



HEADLAMP -CONVENTIONAL TYPE-


Bulb Replacement HEADLAMP

EKS004PA

1. Disconnect connector of headlamp.
2. Unlock retaining spring, then remove bulb.

Headlamp (Low) : 12V - 55W (H7)

Headlamp (High) : 12V - 55W (H7)



CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

1. Turn the bulbsocket counterclockwise and unlock it.
2. Remove the bulb from its socket.

Clearance lamp : 12V - 5W

Front turn signal lamp : 12V - 21W


CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock rubber cap to ensure watertightness.

Removal and Installation REMOVAL

EKS004PB

1. Disconnect connector of headlamp and clearance lamp.
2. Remove the front grille. Refer to [EI-12. "FRONT GRILL"](#).
3. Remove the headlamp mounting bolts.
4. Pull the headlamp toward the front of the vehicle.



INSTALLATION

- Install in the reverse order of removal, taking care of the following points.
Headlamp mounting screws and nut

Tightening torque : 4.4 - 5.8 N·m (0.45 - 0.59 kg-m, 39 - 51 in-lb)

HEADLAMP - XENON TYPE -

PFP:26010

System Description

EKS004PC

The headlamps are controlled by lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 8
- through 15A fuse (No. 41, located in the fuse and fusible link box) and
- to lighting switch terminal 5
- through 15A fuse (No. 42, located in the fuse and fusible link box) and
- to headlamp LH relay terminal 3
- through 20A fuse (No. 37, located in the fuse and fusible link box) and
- to headlamp RH relay terminal 3
- through 20A fuse (No. 36, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from terminal 5 of each headlamp relay
- to terminal 5 of each headlamps

Terminal 3 of each headlamp supplies ground through body grounds E10 and E58.

With power and ground supplied, the low beams will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied.

- from lighting switch terminal 6
- to terminal 4 of headlamp RH, and
- from lighting switch terminal 9
- to terminal 4 of headlamp LH, and
- to combination meter terminal 20 (LHD models) or 7 (RHD models) for the HIGH BEAM indicator.

Ground is supplied to terminal 21 (LHD models) or 8 (RHD models) of the combination meter through body grounds M16, M50 and M70 (Gasoline engine models) or through body grounds M16, M50, M70 and F115 (Diesel engine models).

Ground is supplied to terminal 2 of each headlamp through body grounds E10 and E58.

With power and ground supplied, the high beams and HIGH BEAM indicator illuminate.


Xenon type headlamp is adopted to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Following are some of the many advantages of the xenon type headlamp.

- The light produced by the headlamps is white color approximating sunlight that is easy on the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- The light features a high relative spectral distribution at wavelengths to which the human eye is most sensitive, which means that even in the rain, more light is reflected back from the road surface toward the vehicle, for added visibility.

HEADLAMP - XENON TYPE -


- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.



HEADLAMP - XENON TYPE -

Wiring Diagram - H/LAMP -

EKS004PD



26	25	24	23	22	21	20	19	18	17	16	15	14
13	12	11	10	9	8	7	6	5	4	3	2	1

M36

L

1	2	3		4	5	6	7	
8	9	10	11	12	13	14	15	16

E109

W

2	1	3		8	25
10	7	6	5	9	12




E115

 BR

HEADLAMP - XENON TYPE -

LT-H/LAMP-03

A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA0003E

HEADLAMP - XENON TYPE -

WARNING:

- The xenon headlamp has a high-tension current generating area. Be extremely careful when removing and installing. Be certain to disconnect the battery negative cable prior to removing or installing.
- When the xenon headlamp is lit, do not touch the harness (covered with red or amber insulation), bulb itself or the bulb socket with your bare hands.
- Never service a xenon headlamp with wet hands.
- When checking body side harness with a circuit tester, be certain to disconnect the harness connector from the xenon headlamp.
- When the xenon headlamp is lit, the xenon bulb must be installed in the headlamp housing. (Never turn on xenon headlamp, if the bulb is out of the headlamp housing.)

CAUTION:

Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.

Trouble Diagnosis

EKS004PE

Symptom	Possible cause	Repair order
LH or RH xenon headlamp (low beam) blinks, lacks brightness or does not illuminate.	1. 20A fuse 2. Relay 3. Power supply circuit to headlamp low beam 4. Xenon bulb 5. HID control unit and booster	1. Check 20A fuse [No. 37: LH, No. 36: RH, located in fuse and fusible link box]. 2. Check Headlamp relay. 3. Verify battery positive voltage is present at terminal 5 of headlamp harness with lighting switch in "2nd" and "Low" positions. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.) 4. Replace the xenon bulb with the other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) 5. Replace the HID control unit and booster as a headlamp assembly.
LH or RH [both headlamp high and xenon (low) beam] do not illuminate.	1. Bulb 2. 15A fuse 3. Relay 4. Ground circuit 5. Lighting switch	1. Check bulb. 2. Check 15A fuse [No. 41: LH, No. 42: RH located in fuse and fusible link box]. 3. Check headlamp relay. 4. Check continuity between headlamp terminal 2 and body ground. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.) 5. Check lighting switch.

HEADLAMP - XENON TYPE -

Symptom	Possible cause	Repair order
LH or RH headlamp high beam does not illuminate.	<ol style="list-style-type: none"> 1. Bulb 2. Power supply circuit to headlamp high beam 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Verify battery positive voltage is present at terminal 4 of headlamp harness with lighting switch in "2nd" and "HIGH" position. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.) 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Grounds M16, M50 and M70 2. Open in high beam circuit 3. Combination meter 	<ol style="list-style-type: none"> 1. Check the following. <ul style="list-style-type: none"> – grounds M16, M50 and M70 (Gasoline engine) – grounds M16, M50, M70 and F115 (Diesel engine) 2. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) LHD or 7 (BR/R) RHD for an open circuit. 3. Check combination meter.

HID: High Intensity Discharge

Aiming Adjustment

EKS004PF

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.


If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).


LOW BEAM

1. Turn headlamp low beam on.
LHD models



HEADLAMP - XENON TYPE -

RHD models



2. Use adjusting pots to perform aiming adjustment.

- First tighten the adjusting pot all the way and then make adjustment by loosening the pot.

If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines to point P in illustration show center of headlamp.


“H” : Horizontal center line of headlamps

“WL” : Distance between each headlamp center

“L” : 25 m (98.43 in)

“C” : 250 mm (9.84 in)

- Basic illuminating area for adjustment should be within the range shown in the figure. Adjust headlamps accordingly.



Bulb Replacement

CAUTION:

- After replacing a new xenon bulb, be sure to make aiming adjustments.
- Hold only the plastic base when handling the bulb. Never touch the glass envelope.
- Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

1. Disconnect negative battery cable.
2. Disconnect headlamp connector.

WARNING:

Never service a xenon headlamp with wet hands.

XENON BULB (LOW BEAM)

1. Remove washer inlet. (RH bulb)
2. Remove headlamp seal cover.

HEADLAMP - XENON TYPE -


Turn bulb socket counterclockwise and unlock it.

3. Release retaining pin.
4. Remove the xenon bulb.
5. Install in the reverse order of removal.

Headlamp (LOW) : 12V - 35W (D2R)

CAUTION:

- When disposing of the xenon bulb, do not break it; always dispose of it as is.
- Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.



HIGH BEAM

1. Pull off headlamp seal cover.
2. Disconnect bulb connector.
3. Release retaining pin.
4. Remove the bulb.
5. Install in the reverse order of removal.

Headlamp (HIGH) : 12V - 55W (H7)

CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

Refer to [LT-9, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#) .

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock rubber cap to ensure watertightness.

Removal and Installation

REMOVAL

Refer to [LT-9, "REMOVAL"](#) .

INSTALLATION

Refer to [LT-9, "INSTALLATION"](#) .

EKS004PH

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

PFP:26010

System Description DESCRIPTION

EKS005LP

The headlamp system for Northern Europe vehicles contains a daytime light control unit that activates the low beam headlamps whenever the engine is running.

Power is supplied at all times

- to daytime light control unit terminal 1
- to lighting switch terminal 11
- through 10A (No. 32, located in the fuse and fusible link box), and
- to daytime light control unit terminal 3
- to lighting switch terminal 5
- through 15A (No. 42, located in the fuse and fusible link box), and
- to daytime light control unit terminal 2
- to lighting switch terminal 8
- through 15A (No. 41, located in the fuse and fusible link box)

Ground is supplied to daytime light control unit terminal 9 through body grounds E10, E58 and E122.

When the ignition switch is in the ON or START position, power is supplied

- to daytime light control unit terminal 7
- through 10A (No. 10, located in the fuse and fusible link box)

When the ignition switch is in the START position, power is also supplied

- to daytime light control unit terminal 6
- through 10A (No. 21, located in the fuse and fusible link box)

HEADLAMP OPERATION (DAYTIME CANCEL OPERATION)

For description, refer to [LT-5. "System Description"](#).

When the lighting switch is turn to 1st or 2nd position, power is supplied

- through lighting switch terminal 12
- to daytime light control unit terminal 11

Then daytime light will be canceled. And the lighting system operation will be the same as no daytime unit.

DAYTIME LIGHT OPERATION

When the engine running, the lighting switch in the OFF position, power is supplied


- from alternator terminal 3
- to daytime light control unit terminal 8 and
- from daytime light control unit terminal 2
- through daytime light control unit terminal 5
- to terminal 5 of LH headlamp, and
- from daytime light control unit terminal 3,
- through daytime light control unit terminal 4
- to terminal 5 of RH headlamp and
- from daytime light control unit terminal 1
- through daytime light control unit terminal 10

Ground is supplied to terminal 3 of each headlamp through body grounds E10 and E58.

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Schematic

EKS005LQ



LT

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -



Wiring Diagram — DTRL —

EKS005LR

LT-DTRL-01

⬡ : WITH GASOLINE ENGINE

REFER TO PG-POWER.






REFER TO THE FOLLOWING.

⬡, ⬡ - FUSE BLOCK- JUNCTION BOX (J/B)

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

LT-DTRL-02




MKWA0006E

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

LT-DTRL-03

(G) : WITH GASOLINE ENGINE



26	25	24	23	22	21	20	19	18	17	16	15	14
13	12	11	10	9	8	7	6	5	4	3	2	1

(M36)
L

1	2	3	4	5
---	---	---	---	---

(E26), (E47)

1	2
5	7
3	6

(E27)
BR

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(E109)
W

1
2

(F106)
W

MKWA0573E

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Terminal and Reference Value for Daytime Light Control Unit

EKS005M0

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)
1	B/R	Power source	Ignition switch "OFF"	Battery voltage
2	R	Power source	Ignition switch "OFF"	Battery voltage
3	R/W	Power source	Ignition switch "OFF"	Battery voltage
4	PU	RH low beam	When lighting switch is turned to the 2ND position	Battery voltage
			When engine is running and turning lighting switch to "OFF" (daytime light operation)	Battery voltage
5	R/Y	LH low beam	When lighting switch is turned to the 2ND position	Battery voltage
			When engine is running and turning lighting switch to "OFF" (daytime light operation)	Battery voltage
6	B/Y	Start signal	When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "ON" from "START"	Less than 1V
			When turning ignition switch to "OFF"	Less than 1V
7	Y/G	Power source	When turning ignition switch to "ON"	Battery voltage
			When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
8	Y/R	Alternator	When turning ignition switch to "ON"	Less than 1V
			When engine is running	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
9	B	Ground	—	—
10	R/B	Tail lamp	When turning ignition switch to "ON"	0V
			When engine is running and turning lighting switch to "OFF" (daytime light operation*)	Battery voltage
			When turning ignition switch to "OFF"	0V
11	W/R	Lighting switch	When turning lighting switch to 1ST or 2ND	Battery voltage
			When turning ignition switch to "OFF"	0V

*: Daytime light operating: Lighting switch in "OFF" position with engine running.

Trouble Diagnoses

EKS005LS

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 (R/W) of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 (R) of lighting switch. 4. Check lighting switch.

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Symptom	Possible cause	Repair order
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the following for an open circuit. <ul style="list-style-type: none"> – Continuity between lighting switch terminal 10 (R/Y) and daytime light relay terminal 5 (R/Y) – Continuity between daytime light relay terminal 3 (R/Y) and headlamp LH terminal 5 (R/Y) 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 10 (R/Y) and LH headlamp terminal 5 (R/Y) for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the following for an open circuit. <ul style="list-style-type: none"> – Continuity between lighting switch terminal 10 (R/Y) and daytime light relay terminal 5 (R/Y) – Continuity between daytime light relay terminal 3 (R/Y) and headlamp LH terminal 5 (R/Y) 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 7 (PU) and RH headlamp terminal 5 (PU) for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) for an open circuit.
LH and RH low beam does not operate.	<ol style="list-style-type: none"> 1. Relay 2. Lighting switch 	<ol style="list-style-type: none"> 1. Check daytime light relay. 2. Check lighting switch.
LH low beam does not operate (with daytime operation) but LH low beam operates (with lighting switch 1st or 2nd position).	<ol style="list-style-type: none"> 1. 15A fuse 2. Daytime light circuit 3. Daytime light control unit 	<ol style="list-style-type: none"> 1. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 2 (R/W) of daytime light control unit. 2. Check continuity between daytime light control unit terminal 5 (R/Y) and headlamp LH terminal 5 (R/Y). 3. Check daytime light unit. Refer to LT-23.
RH low beam does not operate (with daytime operation) but RH low beam operates (with lighting switch 1st or 2nd position).	<ol style="list-style-type: none"> 1. 15A fuse 2. Daytime light circuit 3. Daytime light control unit 	<ol style="list-style-type: none"> 1. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 (R) of daytime light control unit. 2. Check continuity between daytime light control unit terminal 4 (PU) and headlamp RH terminal 5 (PU). 3. Check daytime light unit. Refer to LT-23.

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Aiming Adjustment

EKS004PN

Refer to [LT-7, "Aiming Adjustment"](#) .

Bulb Replacement
HEADLAMP

EKS005LT

Refer to [LT-9, "Bulb Replacement"](#) .

CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

Refer to [LT-9, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L

M

HEADLAMP (WITH DAYTIME) - XENON TYPE -

HEADLAMP (WITH DAYTIME) - XENON TYPE -

PFP:26010

System Description


EKS0054P

For headlamp operation, refer to [LT-10, "System Description"](#) .

For daytime operation, refer to [LT-18, "System Description"](#) .

A
B
C
D
E
F
G
H
I
J
K
L
M

EKS004PP



HEADLAMP (WITH DAYTIME) - XENON TYPE -



Wiring Diagram - DTRL -

EKS004PQ

LT-DTRL-04

G : WITH GASOLINE ENGINE

REFER TO PG-POWER.






REFER TO THE FOLLOWING.

M1, M2 - FUSE BLOCK- JUNCTION BOX (J/B)


MKWA0574E

LT-DTRL-05



HEADLAMP (WITH DAYTIME) - XENON TYPE -

LT-DTRL-06



26	25	24	23	22	21	20	19	18	17	16	15	14
13	12	11	10	9	8	7	6	5	4	3	2	1

(M36)
L

3
5
1
2

(E14), (E20)
L

1	2	3	4	5
---	---	---	---	---

(E26), (E47)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(E109)
W

1
2

(F106)
W

MKWA0576E

HEADLAMP (WITH DAYTIME) - XENON TYPE -

Terminal and Reference Value for Daytime Light Control Unit

EKS005M1

Refer to [LT-23, "Terminal and Reference Value for Daytime Light Control Unit"](#).

Trouble Diagnoses

EKS004PR

DAYTIME LIGHT UNIT INSPECTION TABLE

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 (R/W) of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 (R) of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the following for an open circuit. <ul style="list-style-type: none"> – Continuity between lighting switch terminal 10 (R/Y) and daytime light relay terminal 5 (R/Y) – Continuity between daytime light relay terminal 3 (R/Y) and headlamp LH terminal 5 (R/Y) 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 10 (R/Y) and LH headlamp terminal 5 (R/Y) for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the following for an open circuit. <ul style="list-style-type: none"> – Continuity between lighting switch terminal 10 (R/Y) and daytime light relay terminal 5 (R/Y) – Continuity between daytime light relay terminal 3 (R/Y) and headlamp LH terminal 5 (R/Y) 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 7 (PU) and RH headlamp terminal 5 (PU) for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) for an open circuit.

HEADLAMP (WITH DAYTIME) - XENON TYPE -

Symptom	Possible cause	Repair order
LH and RH low beam does not operate.	1. Relay 2. Lighting switch	1. Check daytime light relay. 2. Check lighting switch.
LH low beam does not operate (with daytime operation) but LH low beam operates (with lighting switch 1st or 2nd position).	1. 15A fuse 2. Daytime light circuit 3. Daytime light control unit	1. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 2 (R/W) of daytime light control unit. 2. Check continuity between daytime light control unit terminal 5 (R/Y) and headlamp LH terminal 5 (R/Y). 3. Check daytime light unit. Refer to LT-23 .
RH low beam does not operate (with daytime operation) but RH low beam operates (with lighting switch 1st or 2nd position).	1. 15A fuse 2. Daytime light circuit 3. Daytime light control unit	1. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 3 (R) of daytime light control unit. 2. Check continuity between daytime light control unit terminal 4 (PU) and headlamp RH terminal 5 (PU). 3. Check daytime light unit. Refer to LT-23 .

Bulb Replacement

EKS004PS

Refer to [LT-16, "Bulb Replacement"](#).

Aiming Adjustment

EKS004PT


Refer to [LT-15, "Aiming Adjustment"](#).

HEADLAMP AIMING CONTROL (MANUAL)

Removal and Installation

EKS004T7


1. Remove the Instrument lower driver panel. Refer to [IP-7, "INSTRUMENT LOWER DRIVER PANEL"](#).
2. Press the headlamp aiming switch fixing tabs and remove the unit from the instrument lower driver panel.



Switch Circuit Inspection

EKS004T8

Using a circuit tester, check continuity between the headlamp aiming switch connector terminals in each operation status of the aiming switch.



HEADLAMP AIMING CONTROL (AUTO)

HEADLAMP AIMING CONTROL (AUTO)

PFP:53821

System Description


EKS004T9

The height sensor is designed to adjust the beam angle of the headlamp in response to the loading conditions of the vehicle and vehicle speed. It is not designed to compensate for the dynamic handling of the vehicle. The vehicle rear height is measured by height sensor attached to the rear suspension lateral link arm. Height sensor receives vehicle speed signal from combination meter. The height sensor calculates the correct headlamp aiming position and sends a signal to the aiming motors.

Component Parts and Harness

EKS004TA

CONNECTOR LOCATION





A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP AIMING CONTROL (AUTO)

Wiring Diagram - H/AIM -

EKS004TB

LT-H/AIM-02











REFER TO THE FOLLOWING.

(M1) -FUSE BLOCK-
JUNCTION BOX (J/B)

HEADLAMP AIMING CONTROL (AUTO)

LT-H/AIM-03

- L : LHD MODELS
- R : RHD MODELS
- RE : RHD MODELS WITH ESP/TCS/ABS CONTROL UNIT
- RO : RHD MODELS WITHOUT ESP/TCS/ABS CONTROL UNIT
- *1 11 : L
- 23 : RE
- 11 : RO



MKWA0579E


HEADLAMP AIMING CONTROL (AUTO)

CONSULT-II


EKS0047C

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect CONSULT-II to data link connector.




3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "Headlamp Levelizer".



6. Perform each diagnostic item according to each service procedure.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT-II DIAGNOSTIC TEST MODE		Description
WORK SUPPORT	SENSOR INITIALISE	Replacement or adjustment of height sensor are necessary.
	SENSOR CUSTOMIZE	Change the height sensor current setting.


HEADLAMP AIMING CONTROL (AUTO)

CONSULT-II DIAGNOSTIC TEST MODE	Description
SELF-DIAGNOSTIC RESULTS	Detected items (screen terms) are as shown in the LT-39, "SELF-DIAGNOSTIC RESULTS ITEM CHART"
ACTIVE TEST	This test is able to power supply from height sensor to headlamp aiming motor. This system can be operated.


INITIALIZATION

After the replacement or adjustment of height sensor, the system must be calibrated, This is achieved as follows.

1. Touch "WORK SUPPORT".




2. Touch "SENSOR INITIALISE".



3. Touch "START".

Confirm that "INITIALISE COMPLETE" is displayed on CONSULT-II, close by touching "END".

After successful calibration the headlamps must then be aimed in the conventional manner [LT-15, "Aiming Adjustment"](#) .



SELF-DIAGNOSTIC RESULTS ITEM CHART

Detected items (Screen terms)	System Condition	Reference item
ECU trouble	Height sensor error	Replace height sensor.
No initialisation	Initialisation not done	Refer to LT-39, "INITIALIZATION" .
Sensor out of range	Sensor left specified range	Replace height sensor.
Sensor not plausible	Sensor signal constant for more than 60s while car is moving.	Replace height sensor.
Supply voltage low	Supply voltage below 9V	Refer to LT-40, "Check Power and Ground for Height Sensor" .
Light signal open line	Open line at low beam switch	Refer to LT-40, "Check Lighting Switch Circuit" .
Speed frequency error	Frequency of speed line over specified limit	Refer to LT-41, "Check Speed Signal Circuit" .

HEADLAMP AIMING CONTROL (AUTO)

Detected items (Screen terms)	System Condition	Reference item
Actuator shorted to ground	Calculated output value differs from measured output value.	Refer to LT-42, "Check Headlamp Aiming Motor" .
Actuator shorted to battery	Calculated output value differs from measured output value.	Refer to LT-42, "Check Headlamp Aiming Motor" .

Check Power and Ground for Height Sensor

EKS0054Z

1. POWER SUPPLY CIRCUIT CHECK

Height sensor power supply check


Terminals			Ignition switch position		
(+) (+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
B152	2 (Y/G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between height sensor and fuse



2. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check continuity between height sensor connector B152 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Height sensor OK.

NG >> Repair or replace harness connector.



Check Lighting Switch Circuit

EKS005LU

1. LIGHTING SWITCH INPUT SIGNAL CHECK


1. Disconnect height sensor connector.
2. Turn ignition switch ON.
3. Check voltage between height sensor connector B152 terminal 6 (R/Y) and ground.

Condition for lighting switch	Voltage [V]
Lighting switch in 2ND position	Approx. 12
Except for superscription	Approx. 0

OK or NG

OK >> Replace the height sensor.

NG >> GO TO 2.



HEADLAMP AIMING CONTROL (AUTO)

2. LIGHTING SWITCH OPEN CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check harness continuity between height sensor connector B152 terminal 6 (R/Y) and lighting switch terminal connector E115 terminal 10 (R/Y).

Continuity should exist.

OK or NG

OK >> Check combination switch [LT-93, "Switch Circuit Inspection"](#).

NG >> Repair or replace harness.



Check Speed Signal Circuit

1. SPEED SIGNAL CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check continuity between height sensor connector B152 terminal 6 (SB) and combination meter connector M37 terminal 35 (LHD MODELS) or 48 (RHD MODELS).

Continuity should exist.


4. Check continuity between height sensor connector B152 terminal 1 (B) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness.



2. SPEED SIGNAL SHORT CIRCUIT CHECK


1. Turn ignition switch ON.
2. Check speed signal between combination meter connector M37 terminal 35 (LHD MODELS) or 48 (RHD MODELS) and ground.

Terminals		Shape of waves
(+)	(-)	
Connector	Terminal (Wire color)	
M37	35 (SB)	
	48 (SB)	
	Ground	

OK or NG

OK >> Replace the height sensor.

NG >> Replace the combination meter.



HEADLAMP AIMING CONTROL (AUTO)

EKS00552

Check Headlamp Aiming Motor

1. HEADLAMP AIMING MOTOR CIRCUIT CHECK


1. Disconnect height sensor connector.
2. Check continuity between height sensor connector B152 terminal 7 (BR/W) and headlamp aiming motor connector E25 (RH) terminal 2 (BR/W) or E50 (LH) terminal 2 (BR/W).

Continuity should exist.

OK or NG

OK >> GO TO 2.


NG >> Repair or replace harness.



2. POWER SUPPLY CIRCUIT CHECK

1. Connect height sensor connector.
2. Check voltage between headlamp aiming motor connector E25 (RH) terminal 3 (Y/G) or E50 (LH) terminal 3 (Y/G) and ground.

Terminals			Ignition switch position		
(+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
E25	3 (Y/G)	Ground	0V	0V	Battery voltage
E50					



OK or NG

OK >> GO TO 3.


NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between headlamp aiming motor and fuse

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect headlamp aiming motor connector.
3. Check continuity between headlamp aiming motor connector E25 (RH) terminal 1 (B) or E50 (LH) terminal 1 (B) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (wire color)		
E25	1 (B)	Ground	YES
E50			



OK or NG

OK >> Replace the headlamp aiming motor.


NG >> Repair or replace harness.

HEADLAMP AIMING CONTROL (AUTO)

Removal and installation

EKS004TD

Hight sensor



: N·m (kg-m, ft-lb)

MKIB0257E

LT

L

M

TURN SIGNAL AND HAZARD WARNING LAMPS

PFP:26120

System Description

EKS003TP

The turn signal and hazard warning lamps operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit.

Power is supplied at all time

- to smart entrance control unit terminal 56,
- to flasher sounder terminal 1 and
- to combination meter terminal 52 (LHD models) or 39 (RHD models)
- through 10A fuse [No. 12, located in the fuse block (J/B)].

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- to smart entrance control unit terminal 29
- through 10A fuse [No. 10, located in the fuse block (J/B)], and
- to combination meter terminal 51 (LHD models) or 38 (RHD models)
- through 10A fuse [No. 30, located in the fuse block (J/B)].

LH Turn

When the turn signal switch is moved to the LH position, ground is supplied

- to smart entrance control unit terminal 25 from turn signal switch terminal 3
- through turn signal switch terminal 1
- through body grounds E10 and E58.

Power is supplied from smart entrance control unit terminal 64

- to front turn signal lamp LH terminal 1,
- to side turn signal lamp LH terminal 1,
- to rear combination lamp LH terminal 5 (for sedan models),
- to rear combination lamp LH terminal 1 (for wagon models) or
- to rear combination lamp LH terminal 3 (for hatchback models).

Ground is supplied to the front turn signal lamp LH terminal 2 through body grounds E10 and E58.

Ground is supplied to the side turn signal lamp LH terminal 2 through body grounds E10 and E58.

Ground is supplied to the rear combination lamp LH terminal 4 through body grounds B17 and B24 (for sedan models).

Ground is supplied to the rear combination lamp LH terminal 4 through body grounds B17, B24 and D94 (for wagon models).

Ground is supplied to the rear combination lamp LH terminal 5 through body grounds B17, B24 and B55 (for hatchback models).

With power and ground supplied, the smart entrance control unit controls the flashing of the LH turn signal lamps, and smart entrance control unit sent LH turn signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminal 8 and 11.

Turn signal LH is flushing of combination meter.

RH Turn

When the turn signal switch is moved to the RH position, ground is supplied

- to smart entrance control unit terminal 26 from turn signal switch terminal 2
- through turn signal switch terminal 1 and
- through body grounds E10 and E58.

Power is supplied from smart entrance control unit terminal 63

- to front turn signal lamp RH terminal 1,
- to side turn signal lamp RH terminal 1,
- to rear combination lamp RH terminal 2 (for sedan models),

TURN SIGNAL AND HAZARD WARNING LAMPS

- to rear combination lamp RH terminal 1 (for wagon models) or
- to rear combination lamp RH terminal 4 (for hatchback models).

Ground is supplied to the front turn signal lamp RH terminal 2 through body grounds E10 and E58.

Ground is supplied to the side turn signal lamp RH terminal 2 through body grounds E10 and E58.

Ground is supplied to the rear combination lamp RH terminal 3 through body grounds B17 and B24 (for sedan models).

Ground is supplied to the rear combination lamp RH terminal 4 through body grounds B17, B24 and D94 (for wagon models).

Ground is supplied to the rear combination lamp RH terminal 2 through body grounds B17, B24 and B55.

With power and ground supplied, the smart entrance control unit controls the flashing of the RH turn signal lamps, and smart entrance control unit sent RH turn signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminal 8 and 11.

HAZARD LAMP OPERATION

When the hazard switch in the ON position

Ground supplied

- to smart entrance control unit terminal 30 from hazard switch terminal 1
- through hazard switch terminal 3
- through body grounds M16, M48 and M50.

Power is supplied from smart entrance control unit terminal 64

- to front turn signal lamp LH terminal 1,
- to side turn signal lamp LH terminal 1,
- to rear combination lamp LH terminal 5 (for sedan models),
- to rear combination lamp LH terminal 1 (for wagon models) or
- to rear combination lamp LH terminal 3 (for hatchback models).

Power is supplied from smart entrance control unit terminal 63

- to front turn signal lamp RH terminal 1,
- to side turn signal lamp RH terminal 1,
- to rear combination lamp RH terminal 2 (for sedan models),
- to rear combination lamp RH terminal 1 (for wagon models) or
- to rear combination lamp RH terminal 4 (for hatchback models).

Ground is supplied to terminal 2 each front turn signal lamp through body grounds E10 and E58.

Ground is supplied to terminal 2 each side turn signal lamp through body grounds E10 and E58.

Ground is supplied to terminal 3 (LH) or 4 (RH) of rear combination lamp through body grounds B17 and B24 (for sedan models).

Ground is supplied to terminal 4 each rear combination lamp through body grounds B17, B24 and D94 (for wagon models).

Ground is supplied to terminal 5 (LH) or 2 (RH) of rear combination lamp through body grounds B17, B24 and B55 (for hatchback models).

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps, and smart entrance control unit sent hazard warning signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminals 8 and 11.

TURN SIGNAL (HAZARD) SOUND OPERATION

When turn signal (hazard) is operated, power is supplied

- to smart entrance control unit terminal 12
- thorough flasher sounder terminal 3.

Turn signal (hazard) signal is triggered when the signal is followed as a moment (850 μ S). Then turn signal (hazard) sound will be sounded.

TURN SIGNAL AND HAZARD WARNING LAMPS

MULTI-REMOTE CONTROL SYSTEM OPERATION

When smart entrance control unit receives LOCK or UNLOCK signal from remote controller with all doors closed, power is supplied

- through smart entrance control unit terminal 64
- to front turn signal lamp LH terminal 1,
- to side turn signal lamp LH terminal 1,
- to rear combination lamp LH terminal 5 (for sedan models),
- to rear combination lamp LH terminal 1 (for wagon models) or
- to rear combination lamp LH terminal 3 (for hatchback models), and
- through smart entrance control unit terminal 63.
- to front turn signal lamp RH terminal 1,
- to side turn signal lamp RH terminal 1,
- to rear combination lamp RH terminal 2 (for sedan models),
- to rear combination lamp RH terminal 1 (for wagon models) or
- to rear combination lamp RH terminal 4 (for hatchback models).

Ground is supplied to terminal 2 each front turn signal lamp through body grounds E10 and E58.

Ground is supplied to terminal 2 each side turn signal lamp through body grounds E10 and E58.

Ground is supplied to terminal 3 (LH) or 4 (RH) of rear combination lamp through body grounds B17 and B24 (for sedan models).

Ground is supplied to terminal 4 each rear combination lamp through body grounds B17, B24 and D90 (for wagon models).

Ground is supplied to terminal 5 (LH) or 2 (RH) of combination lamp through body grounds B17, B24 and B55.


With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps. and smart entrance control unit sent hazard warning signal to combination meter with CAN communication line. Refer to [LT-126, "CAN COMMUNICATION"](#) .

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminals 8 and 11

Turn signal is flashing of combination meter.

Schematic

EKS005LX





MKWA0781E



TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

EKS0037Q





REFER TO THE FOLLOWING.
(M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)



TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03

(S) : SEDAN

(H) : HATCHBACK

(W) : WAGON

(L) : LHD MODELS



(R) : RHD MODELS

*1 16 : (L)


19 : (R)

*2 17 : (L)


20 : (R)




(B3)
W




(B38), (B39)




(B48)
BR




(B59), (B91)



(B61), (B63)
W W



(B62), (B64)



(D83)
W

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal and Reference Valve for Smart Entrance Control Unit

EKS00553

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
8	L	CAN communication line	—	—
11	R	CAN communication line	—	—
12	PU/W	Flasher sounder	Flasher sounder signal: Triggered (0V) Not triggered (12V)	12V → 0V (850 μs) → 12V
25	G/B	Combination switch (Turn signal switch)	Turn signal switch: Neutral → Left turn position	12V → 0V
26	G/Y	Combination switch (Turn signal switch)	Turn signal switch: Neutral → Right turn position	12V → 0V
29	Y/G	Ignition key switch	Ignition key is in "ON" position	12V
30	G/R	Hazard switch	Hazard switch: OFF → ON	12V → 0V
53	B	Ground	—	0V
56	R/B	Power source	—	12V
63	G/Y	RH turn signal lamp	[When door lock or unlock is operated using remote controller] Turn signal lamp: OFF → ON → OFF	0V → 12V → 0V
64	G/B	LH turn signal lamp	[When door lock or unlock is operated using remote controller] Turn signal lamp: OFF → ON → OFF	0V → 12V → 0V

Turn Signal And Hazard Warning Lamp Do Not Operate

EKS0054Q

1. FUSE CHECK

Check if any of the following fuses in smart entrance control unit.

Unit	Power source	Fuse No.
Smart entrance control unit	Battery	12
	Ignition switch ON or START position	10

OK or NG

OK >> GO TO 3.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK


Check smart entrance control unit power supply.

Terminals			Ignition switch position		
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M43	56 (R/B)	Ground	Battery voltage	Battery voltage	Battery voltage
M42	29 (Y/G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 4.

NG >> Check harness for open or short between smart entrance control unit and fuse.



TURN SIGNAL AND HAZARD WARNING LAMPS


3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect smart entrance control unit connector.
3. Check continuity between smart entrance control unit harness connector M43 terminal 53 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Replace smart entrance control unit.
NG >> Repair or replace harness.



Turn Signal Lamps Do Not Operate But Hazard Warning Lamp Operates

EKS004Q4


1. TURN SIGNAL SWITCH GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect turn signal switch connector.
3. Check continuity between combination switch harness connector E115 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace harness.



2. TURN SIGNAL SWITCH CHECK

Check turn signal switch [LT-93, "Switch Circuit Inspection"](#).

OK or NG

- OK >> Replace smart entrance control unit.
NG >> Replace turn signal switch.

TURN SIGNAL AND HAZARD WARNING LAMPS

Hazard Warning Lamps Do Not Operate But Turn Signal Lamp Operate

EKS0054R

1. CHECK HAZARD SWITCH INPUT SIGNAL

WITH CONSULT-II

Check hazard switch in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
IGNITION SW	ON
HAZARD SW	OFF
RH TURN SW	OFF
LH TURN SW	OFF
RKE LOCK	OFF
RKE UNLOCK	OFF
RKE SEL UNLOCK	OFF
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0194E


WITHOUT CONSULT-II

Check battery voltage between smart entrance control unit harness connector M42 terminal 30 (G/R) and ground.

Condition	Voltage [V]
Hazard switch ON	0
Hazard switch OFF	Battery voltage

OK or NG

- OK >> Hazard switch OK.
- NG >> GO TO 3.




2. HAZARD SWITCH CHECK

- Turn ignition switch OFF.
- Disconnect hazard switch connector.
- Check continuity between hazard switch terminals 1 and 3.

Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Replace the hazard switch.




3. GROUND CIRCUIT CHECK

Check continuity between smart entrance control unit harness connector M42 terminal 30 (G/R) hazard switch harness connector M48 terminal 1 (G/R).

Continuity should exist.

OK or NG

- OK >> Check hazard switch ground circuit.
- NG >> Repair or replace harness.



TURN SIGNAL AND HAZARD WARNING LAMPS

Turn Signal Lamp LH Does Not Operate

EKS005LV

1. BULB CHECK

Check turn signal lamp LH bulb.

OK or NG

OK >> GO TO 3.

NG >> Replace bulb.

2. TURN SWITCH LH INPUT SIGNAL CHECK

Check "LH TURN SW" signal in "DATA MONITOR" mode with CONSULT-II.

OK or NG

OK >> Turn signal switch OK.

NG >> GO TO 4.

DATA MONITOR			
MONITOR			
IGNITION SW	ON		
HAZARD SW	OFF		
RH TURN SW	OFF		
LH TURN SW	OFF		
RKE LOCK	OFF		
RKE UNLOCK	OFF		
RKE SEL UNLOCK	OFF		
		RECORD	
MODE	BACK	LIGHT	COPY

MKIB0194E

3. POWER SUPPLY CIRCUIT CHECK


Check voltage between smart entrance control unit harness connector M43 terminal 64 (G/B) and ground.

Condition	Voltage [V]
Turn signal LH illuminates.	0
Turn signal LH does not illuminate.	Battery voltage

OK or NG

OK >> GO TO 5.

NG >> Replace the smart entrance control unit.



TURN SIGNAL AND HAZARD WARNING LAMPS


4. TURN SIGNAL LAMP LH CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect each turn signal lamps LH connector.
3. Check continuity between the following harness connector terminal of the each turn signal lamps LH and body ground.

Terminals			Continuity
(+) Terminal (Wire color)			
Connector	Terminal (Wire color)		
E51	1 (G/B)	64 (G/B)	Yes
E59	1 (G/B)		
B38 (Wagon models)	1 (G/B)		
B62 (Sedan models)	5 (G/Y)		
B59 (Hatchback models)	3 (G/B)		

OK or NG

- OK >> Check harness for open or short smart between entrance control unit and hazard switch.
- NG >> Repair harness.



Turn Signal Lamp RH Does Not Operate

1. BULB CHECK

Check turn signal lamp RH bulb.

OK or NG

- OK >> GO TO 3.
- NG >> Replace bulb.

2. TURN SWITCH RH INPUT SIGNAL CHECK

Check "RH TURN SW" signal in "DATA MONITOR" mode with CONSULT-II.

OK or NG

- OK >> Turn signal switch OK.
- NG >> GO TO 4.

DATA MONITOR			
MONITOR			
IGNITION SW	ON		
HAZARD SW	OFF		
RH TURN SW	OFF		
LH TURN SW	OFF		
RKE LOCK	OFF		
RKE UNLOCK	OFF		
RKE SEL UNLOCK	OFF		
		RECORD	
MODE	BACK	LIGHT	COPY

MKIB0194E

TURN SIGNAL AND HAZARD WARNING LAMPS

3. POWER SUPPLY CIRCUIT CHECK


Check voltage between smart entrance control unit harness connector M43 terminal 63 (G/Y) and ground.

Condition	Voltage [V]
Turn signal RH illuminates.	0
Turn signal RH does not illuminate.	Battery voltage

OK or NG

OK >> GO TO 5.

NG >> Replace the smart entrance control unit.



4. TURN SIGNAL LAMP RH CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect each turn signal lamp RH connector.
3. Check continuity between the following harness connector terminal of the each turn signal lamp RH and body ground.

Terminals		Continuity
(+)	(-)	
Connector	Terminal (Wire color)	
E1	1 (G/Y)	Yes
E24	1 (G/Y)	
B39 (Wagon models)	1 (G/Y)	
B64 (Sedan models)	2 (G/Y)	
B91 (Hatchback models)	4 (G/Y)	
	63 (G/Y)	

OK or NG

OK >> Check harness for open or short between smart entrance control unit and hazard switch.

NG >> Repair harness.



RH and LH Turn Indicators Do Not Operate

1. COMBINATION METER POWER AND GROUND CIRCUIT CHECK

Check combination meter power and ground circuit check.

Refer to [DI-29, "Power Supply and Ground Circuit Check"](#) (LHD) or [DI-59, "Power Supply and Ground Circuit Check"](#) (RHD).

OK or NG

OK >> GO TO 2.

NG >> Replace combination meter.

EKS005LW

TURN SIGNAL AND HAZARD WARNING LAMPS

2. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.

Refer to [BCS-24, "Trouble Diagnoses"](#) .

Does the display of CAN appear?

YES or NO

YES >> Check the CAN communication line. Refer to [BCS-25, "CAN Communication Line Check"](#) .

NO >> Replace combination meter.


Bulb Replacement FRONT TURN SIGNAL LAMP

Front turn signal lamp : 12V - 21W (amber)

SIDE TURN SIGNAL LAMP

1. Remove side turn signal lamp.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from its socket.

Side turn signal lamp : 12V - 5W




REAR TURN SIGNAL LAMP

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

Removal and Installation for Side Turn Signal Lamp

1. Push the side turn signal lamp toward A direction in the figure, and pull up B direction in the figure.
2. Disconnect the side turn signal lamp connector.



Removal and Installation for Rear Turn Signal Lamp

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

LIGHTING AND TURN SIGNAL SWITCH


LIGHTING AND TURN SIGNAL SWITCH

PFP:25540

Removal and Installation

EKS003TX

1. Remove the steering column cover. Refer to [PS-10, "STEERING COLUMN"](#).
2. Remove lighting and turn signal switch mounting screw and remove the lighting and turn signal switch from the spiral cable.



3. Disconnect the lighting and turn signal switch connector.

Switch Circuit Inspection

EKS003TY

Using circuit tester, check continuity between the lighting and turn signal switch connector terminals in each operation status of the switch. Refer to [LT-93, "Switch Circuit Inspection"](#).

HAZARD SWITCH

HAZARD SWITCH


PFP:25290

Removal and Installation

EKS003TZ

REMOVAL

1. Remove cluster lid C. Refer to [IP-6, "CLUSTER LID C"](#) in "INSTRUMENT PANEL (IP)" section.
2. Using a flat-bladed screwdriver or other suitable tool, press pawl to remove hazard switch from cluster lid C.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

LT

L

M

STOP LAMP



PFP:26550

EKS003U0

LT-STOP/L-01

STOP LAMP

Wiring Diagram — STOP/L —





REFER TO THE FOLLOWING.

(M2) -FUSE BLOCK-
JUNCTION BOX (J/B)

STOP LAMP

LT-STOP/L-02

(H) : HATCHBACK





LT

STOP LAMP

LT-STOP/L-03

W : WAGON



STOP LAMP

Bulb Replacement
STOP LAMP

EKS003U1

Refer to [LT-90, "REAR COMBINATION LAMP"](#)

A

Removal and Installation
STOP LAMP

EKS003U2

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

B

C

D

E

F

G

H

I

J

LT

L

M

BACK-UP LAMP



BACK-UP LAMP

PFP:26550

Wiring Diagram — BACK/L —

EKS003U3


LT-BACK/L-01



REFER TO THE FOLLOWING.
(E106) -FUSE BLOCK-
 JUNCTION BOX (J/B)

BACK-UP LAMP

LT-BACK/L-02



1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20							

B5
BR

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24									

B42
GY

1	2	3	4	5	6
---	---	---	---	---	---

B59, B91

1	2	3	4	5	6
---	---	---	---	---	---

B61, B63
B B

1	2	3	4	5	6
---	---	---	---	---	---

B62, B64

1	2	3	4
---	---	---	---

D82
W

1	2
---	---

D83
W

1	2
---	---

D93
W

MKWA0587E

BACK-UP LAMP

Bulb Replacement (Sedan and Hatch Back)

EKS003U4

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

Bulb Replacement (Wagon)

EKS0055D

Refer to [LT-67, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

Removal and Installation (Sedan and Hatch Back)

EKS003U5

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

Removal and Installation (Wagon)


EKS0055E

Refer to [LT-67, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

PARKING, LICENSE PLATE AND TAIL LAMPS
Schematic

PFP:26550

EKS005LY




LT

L

M



Wiring Diagram - TAIL/L -/LHD MODELS

LT-TAIL/L-01



PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02





MKWA0588E

PARKING, LICENSE PLATE AND TAIL LAMPS


LT-TAIL/L-03

 : HATCHBACK



PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-04



1 2 3 4 B38 , B39

1 2 3 4 5 D81
6 7 8 9 10 11 12 W

1 D83
2 W

1 D101
2 W
3

1 2 D102 , D104



MKWA0590E

PARKING, LICENSE PLATE AND TAIL LAMPS

Wiring Diagram - TAIL/L -/RHD MODELS

EKS004QA

LT-TAIL/L-05





REFER TO THE FOLLOWING.

(E106), (B1) -FUSE BLOCK-JUNCTION BOX (J/B)

PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-06





MKWA0592E

PARKING, LICENSE PLATE AND TAIL LAMPS


LT-TAIL/L-07

 : HATCHBACK



PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-08



1 2 3 4 B38 , B39

1 2 3 4 5 D81
6 7 8 9 10 11 12 W

1 D83
2 W

1 D101
2 W
3

1 2 D102 , D103

MKWA0594E

PARKING, LICENSE PLATE AND TAIL LAMPS

Bulb Replacement PARKING AND TAIL LAMPS


EKS003U7

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

LICENSE PLATE LAMP

1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb from its socket.

License plate lamp : 12V - 5W



Removal and Installation PARKING AND TAIL LAMPS


EKS003U8

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .


LICENSE PLATE LAMP

Removal (Sedan and Hatchback)

1. Remove the license lamp finisher. Refer to [EI-21, "LICENSE PLATE FINISHER"](#) .
2. Remove the harness from installation pawl for harness.



3. Push license plate lamp mounting hook.
4. Pull out license plate lamp from finisher.





Installation

- Install license plate lamp in the reverse order of removal.

PARKING, LICENSE PLATE AND TAIL LAMPS

Removal (Wagon)

1. Remove the license lamp finisher. Refer to [EI-21, "LICENSE PLATE FINISHER"](#).
2. Remove the harness from installation pawl for harness.
3. Push license plate lamp mounting hook.
4. Pull out license plate lamp from finisher.



Installation

- Install license plate lamp in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
LT
L
M

FRONT FOG LAMP

FRONT FOG LAMP

PFP:00011

System Description DESCRIPTION

EKS003U9

Power is supplied at all times to fog lamp relay terminal 3

- through 15A fuse (No. 43, located in the fuse and fusible link box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 10A fuse (No. 32, located in the fuse and fusible link box)
- to lighting switch terminal 11,
- through terminal 12 of the lighting switch
- to fog lamp switch terminal 32, and
- through terminal 31 of the fog lamp switch
- to fog lamp relay terminal 1.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 1st or 2nd position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal 2
- through the fog lamp switch and body grounds E10 and E58.

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal 5
- to terminal 1 of each fog lamp, and
- to combination meter terminal 6 (LHD models) or 19 (RHD models) for the FRONT FOG indicator.

Ground is supplied to terminals 24, 25 and 45 (LHD models) or 11, 12 and 32 (RHD models) to the combination meter through body grounds M16, M50 and M70.









Ground is supplied to terminal 2 of each fog lamp through body grounds E10 and E58.

With power and ground supplied, the fog lamps and the front fog indicator illuminate.

FRONT FOG LAMP

Wiring Diagram — F/FOG —

EKS003UA




FRONT FOG LAMP


Aiming Adjustment

EKS003UB


1. Set the top edge of the fog lamp lens as shown in the figure.



2. Turn front fog lamps ON.



3. Adjust front fog lamps as shown in the figure.
 - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



Bulb Replacement


EKS003UC

1. Remove fender protector.
2. Turn bulb counterclockwise then remove it.

Front fog lamp : 12V - 55W (H11)

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock plastic cap to ensure watertightness.



Removal and Installation


REMOVAL

EKS003UD

1. Remove fender protector. Refer to [EI-14, "FENDER PROTECTOR"](#).
2. Disconnect fog lamp connector.

FRONT FOG LAMP

3. Remove fog lamp mounting bolt.
4. Pull out fog lamp from vehicle and disconnect connector.



INSTALLATION

- Install fog lamp in the reverse order of removal, observing the tightening torque shown below.
Fog lamp mounting bolt

 : 3.3 - 7.7 N·m (0.33 - 0.79 kg-m, 29 - 69 in-lb)

A
B
C
D
E
F
G
H
I
J
LT
L
M

REAR FOG LAMP

REAR FOG LAMP

PFP:26550

Wiring Diagram — R/FOG — /Without Front Fog Lamp

EKS003UE


LT-R/FOG-01

REFER TO PG-POWER.

 : WITH GASOLINE ENGINE

 : LHD MODELS

 : RHD MODELS


*1 7: 


20 :

*2 24 :

11:


*3 45 :

32 · 

*4 25 : 


12:

A  **NEXT PAGE**





REFER TO THE FOLLOWING.

**(E105) - FUSE BLOCK-
JUNCTION BOX (J/B)**



REAR FOG LAMP

LT-R/FOG-02




REAR FOG LAMP


Wiring Diagram — R/FOG — /With Front Fog Lamp

EKS003UF

LT-R/FOG-03





26	25	24	23	22	21	20	19	18	17	16	15	14															
13	12	11	10	9	8	7	6	5	4	3	2	1	M36														
													L														
52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27		
													M37													Y	



REAR FOG LAMP

LT-R/FOG-04



REAR FOG LAMP

Bulb Replacement (Sedan and Hatchback)

EKS003UG


Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

Bulb Replacement (Wagon)

EKS0055G

1. Remove the back door mask RH (RHD) or LH (LHD) on the back door finisher.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.

Rear fog lamp : 12V - 21W



EKS003UH

Removal and Installation

REMOVAL (SEDAN AND HATCHBACK)

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

REMOVAL (WAGON)

Refer to [LT-76, "Removal and Installation"](#) .

INSTALLATION (SEDAN AND HATCHBACK)

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

INSTALLATION (WAGON)

Refer to [LT-76, "Removal and Installation"](#) .

CLEARANCE LAMP/TAIL LAMP

CLEARANCE LAMP/TAIL LAMP

PFP:26010

Bulb Replacement (Clearance Lamp)

EKS003UI

Refer to [LT-9, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#) .

Bulb Replacement (Tail Lamp)

EKS003UJ

Refer to [LT-90, "REAR COMBINATION LAMP"](#) .

Removal and Installation of Clearance Lamp

EKS003UK

Refer to [LT-9, "Removal and Installation"](#) .

Removal and Installation of Tail Lamp

EKS003UL

Refer to [LT-91, "Removal and Installation"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L

M

HIGH-MOUNTED STOP LAMP

HIGH-MOUNTED STOP LAMP

PFP:26590


Bulb Replacement

HIGH-MOUNTED STOP LAMP (SEDAN)

EKS003UM

1. Open the trunk lid.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from its socket.


High-mounted stop lamp : 12V - 21W



HIGH-MOUNTED STOP LAMP (WAGON)

1. Remove the high-mounted stop lamp. Refer to "Removal and Installation" below.
2. Turn the high-mounted stop lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb.

High-mounted stop lamp : 12V 5W



HIGH-MOUNTED STOP LAMP (HATCHBACK)

LED bulb is not serviceable.


Replace high-mounted stop lamp assembly.

Removal and Installation

HIGH-MOUNTED STOP LAMP (SEDAN)


EKS003UN

1. Remove the rear parcel shelf. Refer to [EI-32, "REAR PARCEL SHELF FINISHER"](#).
2. Take off front and rear nails, then remove high-mounted stop lamp from rear parcel shelf finisher.



HIGH-MOUNTED STOP LAMP (WAGON)


1. Remove the back door upper garnish. Refer to [EI-24, "BACK DOOR TRIM"](#).
2. Disconnect the high-mounted stop lamp connector.
3. Remove the high-mounted stop lamp mounting bolts.



HIGH-MOUNTED STOP LAMP

HIGH-MOUNTED STOP LAMP (HATCHBACK)

1. Remove the back door upper garnish. Refer to [EI-24, "BACK DOOR TRIM"](#) .
2. Disconnect the high-mounted stop lamp connector.
3. Remove the high-mounted stop lamp mounting bolts.



A
B
C
D
E
F
G
H
I
J
LT
L
M

REAR COMBINATION LAMP

REAR COMBINATION LAMP

PFP:26554

Bulb Replacement (Sedan)

EKS003UP


1. Open the trunk lid and remove wheel house finisher.
2. Remove rear combination lamp mounting nuts (2).
3. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulbs.

Stop/tail lamp : 12V - 21/5W

Rear turn signal lamp : 12V - 21W

Back-up lamp : 12V - 21W

Rear fog lamp : 12V - 21W




Bulb Replacement (Wagon)

EKS0055F

1. Open the back door, and remove rear combination lamp mounting bolts (2).
2. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb.

Stop/tail lamp : 12V - 21/5W

Rear turn signal lamp : 12V - 21W



Bulb Replacement (Hatchback)

EKS005LZ

1. Open the back door, and remove rear combination lamp mounting bolts (2).
2. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
3. Remove bulb holder mounting screws(2) and remove bulb holder from rear combination lamp.

4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulb.



Stop lamp : 12V - 21W

tail lamp : 12V - 5W

Rear turn signal lamp : 12V - 21W

Back-up lamp (RHD) : 12V - 21W

Rear fog lamp (LHD) : 12V - 21W




REAR COMBINATION LAMP

EKS003UQ

Removal and Installation


REMOVAL (SEDAN)

1. Open the trunk lid and remove wheel house finisher.
2. Remove rear combination lamp mounting nuts (2).
3. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
4. Disconnect rear combination lamp connector.
5. From outside the vehicle, remove harness.




REMOVAL (WAGON)

1. Open the back door and remove rear combination lamp mounting bolts (2).
2. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
3. Disconnect rear combination lamp connector.
4. From outside the vehicle, remove harness.



REMOVAL (HATCHBACK)

1. Open the back door and remove rear combination lamp side cover.
2. Remove rear combination lamp mounting bolts (2).
3. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
4. Disconnect rear combination lamp connector.
5. From outside the vehicle, remove harness.



INSTALLATION

Install in the reverse order of removal, paying attention to the following.

Rear combination lamp mounting bolts and nuts:

-  : 2.5 - 3.8 N·m (0.25 - 0.39 kg-m, 23 - 33 in-lb) (SEDAN)
-  : 3.3 - 7.7 N·m (0.34 - 0.79 kg-m, 30 - 68 in-lb) (WAGON)
-  : 3.2 - 5.1 N·m (0.33 - 0.52 kg-m, 29 - 45 in-lb) (HATCHBACK)

COMBINATION SWITCH

COMBINATION SWITCH

PFP:25567

Removal and Installation


EKS003UR

Refer to [SRS-35, "SPIRAL CABLE"](#) in "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)" section for details.

COMBINATION SWITCH

Switch Circuit Inspection

EKS003US



LIGHTING SWITCH
(With front and rear fog lamp)

N	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6									
7									
8									
9									
10									
11									
12									

LIGHTING SWITCH
(With rear fog lamp)

N	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
25									
5									
6									
7									
8									
9									
10									
11									
12									

FOG LAMP SWITCH
(With front and rear fog lamp)

N	OFF	FR	FR+RR
31			
32			
33			

FOG LAMP SWITCH
(With rear fog lamp)

N	OFF	RR
34		
33		

TURN SIGNAL SWITCH

N	R	N	L
1			
2			
3			

MKWA0295E

COMBINATION SWITCH

Refer to [LT-58, "Switch Circuit Inspection"](#) in "LIGHTING AND TURN SIGNAL SWITCH" section, and [WW-8, "Terminal and Reference Values for Combination Switch"](#) , [WW-38, "Terminal and Reference Values for Combination Switch"](#) in " WW Wiper/Washer Horn" section for details.

ILLUMINATION

ILLUMINATION

PFP:27545

System Description

EKS003UT

Power is supplied at all times

- through 10A fuse [No. 32, located in the fuse and fusible link box]
- to lighting switch terminal 11.

The lighting switch must be in the 1ST or 2ND position for illumination.


The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Headlamp aiming switch	E103	1	2
ESP off switch	M8	3	4
Hazard switch	M48	7	8
Combination meter (LHD models)	M36, M37	51, 52	24, 25, 45
Combination meter (RHD models)	M36, M37	38, 39	11, 12, 32
Audio	M51, M53	1	29
A/T device (With A/T)	M65	3	4
A/T device (With CVT)	M66	1	2
Heated seat switch LH	M104	5	6
Heated seat switch RH	M103	5	6
Door lock/unlock switch	M102	4	3
Glove box lamp	M71	2	1
Ashtray illumination	M57	1	2
AV and NAVI control unit	M54, M55	25	5
VFD Display	M61	20	18
LCD Display	M61	8	1, 3
Multifunction switch	M49	4	2

ILLUMINATION

Schematic

EKS003UU




MKW0600E

ILLUMINATION

Wiring Diagram — ILL —

EKS004QB

LT-ILL-01












REFER TO THE FOLLOWING.

(M1), (M2), (E106)

-FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0601E

LT-ILL-02



REFER TO THE FOLLOWING.

(M1) -FUSE BLOCK-
JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

L







M





REFER TO THE FOLLOWING.
(M1), (E106) - FUSE BLOCK-
JUNCTION BOX (J/B)

ILLUMINATION

LT-ILL-04

- *1 W/R :  : WITH GASOLINE ENGINE
 R/G :  : LHD MODELS
 : RHD MODELS
 : WITH A/T
 : WITH CVT
 : WITH ESP/TCS/ABS CONTROL UNIT



MKWA0604E

A
B
C
D
E
F
G
H
I
J
K
L
M

LT



INTERIOR ROOM LAMP

PFP:26410

System Description POWER SUPPLY AND GROUND

EKS0054T

Power is supplied at all times:

- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to key switch terminal 1 and
- to smart entrance control unit terminal 56, and
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to interior room lamp terminal 3,
- to keyhole illumination terminal 2 and
- to each door step lamps terminal 1.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal 2
- to smart entrance control unit terminal 5.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 29.

Ground is supplied:

- through body grounds M16, M50, M70 and F115 (Gasoline engine models) or
- through body grounds M16, M50 and M70 (Diesel engine models)
- to smart entrance control unit terminal 53.

When any door (except back door) is opened, ground is supplied:

- through case ground of each door switch
- to each door switch terminal 1
- to smart entrance control unit terminals 39, 43 and 44, 45.

When the driver side door is unlocked by the door lock/unlock switch, the smart entrance control unit receives a ground signal:

- through body grounds M16, M50, M70 and F115 (Gasoline engine models) or
- through body grounds M16, M50 and M70 (Diesel engine models)
- to door lock/unlock switch terminal 3
- from door lock/unlock switch terminal 2
- to smart entrance control unit terminal 14.

When the driver side door is locked by the door lock/unlock switch, the smart entrance control unit receives a ground signal:

- through body grounds M16, M50, M70 and F115 (Gasoline engine models) or
- through body grounds terminals M16, M50 and M70 (Diesel engine models)
- to door lock/unlock switch terminal 3
- from door lock/unlock switch terminal 1
- to smart entrance control unit terminal 13.

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 28
- to interior room lamp terminal 2.

With power and ground supplied, the interior room lamp illuminates.

SWITCH OPERATION

When interior room lamp switch is ON, ground is supplied:

- through case grounds of interior room lamp
- to interior room lamp.

INTERIOR ROOM LAMP

INTERIOR ROOM LAMP TIMER OPERATION

When interior room lamp switch is in the "DOOR" position, the time control unit keeps the interior room lamp illuminated for about 30 seconds when:

- unlock signal is supplied from driver's door lock/unlock switch while all doors are closed and key is out of ignition key cylinder,
- unlock signal is supplied from remote controller while all doors are closed and key is out of the ignition key cylinder,
- key is removed from ignition key cylinder while all doors are closed, or
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

However, ignition keyhole illumination remains on for about 30 seconds after driver's door has been locked. The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or
- ignition switch is turned ON.

ON-OFF CONTROL


When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position. When any door is opened, step lamps turn ON.

A
B
C
D
E
F
G
H
I
J
LT
L
M

INTERIOR ROOM LAMP

Schematic

EKS004RB



MKWA0606E

INTERIOR ROOM LAMP


Wiring Diagram — ROOM/L —/LHD MODELS

EKS004RC

LT-ROOM/L-01

 : WITH GASOLINE ENGINE

REFER TO PG-POWER.



LT

L

M





REFER TO THE FOLLOWING.

M1, M2, E106

- FUSE BLOCK -

JUNCTION BOX (J/B)





MKWA0607E

INTERIOR ROOM LAMP

LT-ROOM/L-02

PRECEDING
PAGE





MKWA0265E

INTERIOR ROOM LAMP

LT-ROOM/L-03

A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA0608E

INTERIOR ROOM LAMP


Wiring Diagram — ROOM/L —/RHD MODELS

EKS004RD

LT-ROOM/L-04

⬡G⬡ : WITH GASOLINE ENGINE

REFER TO PG-POWER.





REFER TO THE FOLLOWING.

⬡M1⬡, ⬡M2⬡, ⬡E106⬡

- FUSE BLOCK -



JUNCTION BOX (J/B)



MKWA0610E

INTERIOR ROOM LAMP

LT-ROOM/L-05





MKWA0611E

INTERIOR ROOM LAMP

LT-ROOM/L-06

- : WITH ESP/TCS/ABS CONTROL UNIT
 : WITHOUT ESP/TCS/ABS CONTROL UNIT
 : WITH GASOLINE ENGINE

*1 11: *2 24:
 9: 8:



MKWA0612E

INTERIOR ROOM LAMP

Terminal and Reference Valve for Smart Entrance Control Unit


EKS00554

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
5	B/R	Key switch	Ignition key Removed → Inserted	0V → 12V
13	G/Y	Door lock/unlock switches	Neutral → Locks	12V → 0V
14	BR/Y	Door lock/unlock switches	Neutral → Unlocks	12V → 0V
28	R/Y	Interior room lamp	When interior lamp is operated using remote controller (Lamp switch in "DOOR" position)	12V → 0V
29	Y/G	Ignition key switch	Ignition key is in "ON" position	12V
39	BR/W	Rear door switch (LH or RH)	Rear door LH or RH: Open → Closed	0V → 12V
43	R/W	Front door switch	Front door (Driver side): Open → Closed	12V → 0V
44	L/OR	Front door switch (Passenger side)	Front door (Passenger side): Open → Closed	0V → 12V
45	R/Y	Rear door switch (LH or RH)	Rear door LH or RH: Open → Closed	0V → 12V
53	B	Ground	—	0V
56	R/B	Power source	—	12V


CONSULT-II Inspection Procedure "ROOM LAMP"

EKS00555

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



INTERIOR ROOM LAMP


5. Touch "SMART ENTRANCE".



6. Touch "ROOM LAMP".



7. Select diagnosis mode.
"DATA MONITOR" are available for "ROOM LAMP".



CONSULT-II Application Items ROOM LAMP

EKS00556

Data Monitor Mode

Item (CONSULT-II screen terms)	Diagnosed system
IGNITION SW	Indicates [ON/OFF] condition of ignition switch.
KEY IN DETECT	Indicates [ON/OFF] condition of electronic key switch.
DOOR SW DR RR	Indicates [ON/OFF] condition of rear door switch (driver side).
DOOR SW AS RR	Indicates [ON/OFF] condition of rear door switch (passenger side).
AS DOOR SW	Indicates [ON/OFF] condition of front door switch (passenger side).
DR DOOR SW	Indicates [ON/OFF] condition of front door switch (driver side).
CDL LOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch (lock signal).
CDL UNLOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch (unlock signal).
RKE LOCK	Indicates [ON/OFF] condition of lock signal from remote controller.
RKE UNLOCK	Indicates [ON/OFF] condition of unlock signal from remote controller.
RKE SEL UNLOCK	Indicates [ON/OFF] condition of select unlock signal from remote controller.

INTERIOR ROOM LAMP

Interior Room Lamp Timer Does Not Operate

EKS0054U


1. CHECK IGNITION ON SIGNAL

④ WITH CONSULT-II

Check ignition switch ON signal ("IGNITION SW") in "DATA MONITOR" mode with CONSULT-II.

When ignition switch is ON : IGNITION SW ON


When ignition switch is OFF : IGNITION SW OFF



⊗ WITHOUT CONSULT-II

1. Disconnect smart entrance control unit.
2. Check voltage between smart entrance control unit harness connector terminal 29 and ground.

Terminals			Ignition switch position		
(+) Terminal (wire color)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
M42	29 (Y/G)	Ground	0V	0V	Battery voltage



OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

INTERIOR ROOM LAMP


2. CHECK DOOR SWITCH INPUT SIGNAL

WITH CONSULT-II

Check driver door switch signal ("DR DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When driver's door switch is open: DR DOOR SW ON

When driver's door switch is closed: DR DOOR SW OFF



WITHOUT CONSULT-II


1. Connect smart entrance control unit connector.
2. Check voltage between smart entrance control unit harness connector M42 terminal 43 (R/W) and ground.

Condition	Voltage [V]
Driver's door is open.	0
Driver's door is closed.	Approx. 12

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.



3. CHECK DRIVER SIDE DOOR SWITCH


1. Disconnect front door switch (driver side) connector.
2. Check continuity between front door switch (driver side) harness connector B16 terminal 1 and ground.

Condition	Continuity
Front door switch (driver side) is ON (open)	Yes
Front door switch (driver side) is OFF (closed)	No

OK or NG

OK >> Check harness for open or short between smart entrance control unit and front door switch (driver side).

NG >> Replace front door switch (driver side).




INTERIOR ROOM LAMP

4. CHECK DOOR LOCK/UNLOCK SWITCH

WITH CONSULT-II

Check door lock/unlock switch signal ("CDL LOCK SW" or "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT-II.


When door lock/unlock is locked : CDL LOCK SW ON
: CDL UNLOCK SW OFF
When door lock/unlock is unlocked : CDL LOCK SW OFF
: CDL UNLOCK SW ON



WITHOUT CONSULT-II

Check voltage between smart entrance control unit and ground.

Terminals		Condition (Door lock/ unlock switch)	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
M41	13 (GY)	Locked	0
		Unlocked	Approx.12
	14 (BR/Y)	Locked	Approx.12
		Unlocked	0



OK or NG

OK >> GO TO 6.
NG >> GO TO 5.

5. CHECK DOOR LOCK/UNLOCK SWITCH

- Disconnect door lock/unlock switch harness connector.
- Check continuity between door lock/unlock switch harness connector M102 terminals 2 and 3.


Condition	Continuity
Door lock/unlock switch is locked.	No
Door lock/unlock switch is unlocked.	Yes

- Check continuity between door lock/unlock switch harness connector M102 terminals 1 and 3.

Condition	Continuity
Door lock/unlock switch is locked.	Yes
Door lock/unlock switch is unlocked.	No

OK or NG

OK >> Check harness for open or short between smart entrance control unit and door lock/unlock switch.
NG >> Replace lock/unlock switch.



INTERIOR ROOM LAMP

6. CHECK OTHER DOORS SWITCHES INPUT SIGNAL

WITH CONSULT-II

Check other doors switch signal ("AS DOOR SW", "RR DOOR SW" or "RR RH DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When each doors is open: EACH DOOR SW ON

When each doors is closed: EACH DOOR SW OFF


DATA MONITOR	
MONITOR	
AS DOOR SW	ON
RR LH DOOR SW	ON
RR RH DOOR SW	ON

MKIB0199E

WITHOUT CONSULT-II

Check voltage between smart entrance control unit and ground.

Terminals			Condition (Driver's side)	Voltage [V]
(+) (+)		(-)		
Connector	Terminal (wire color)			
M42	39 (BR/W)	Ground	Open	0
			Closed	Approx. 12
	44 (L/OR)	Ground	Open	0
			Closed	Approx. 12
	45 (R/Y)	Ground	Open	0
			Closed	Approx. 12



OK or NG


OK >> GO TO 8.

NG >> GO TO 7.

7. CHECK DOOR SWITCHES

1. Disconnect door switch harness connector.
2. Check continuity between door switch terminal 1 and ground.

Door switch	Connector	Condition (Passenger or rear door)	Continuity
Passenger side	B118	Open	Yes
		Closed	No
Rear RH side	B23	Open	Yes
		Closed	No
Rear LH side	B125	Open	Yes
		Closed	No



OK or NG

OK >> Check harness for open or short between smart entrance control unit and door switch.

NG >> Replace door switch.

INTERIOR ROOM LAMP


8. CHECK KEY SWITCH INPUT SIGNAL

WITH CONSULT-II

Check key switch signal ("KEY IN DETECT") in "DATA MONITOR" mode with CONSULT-II.

When key is inserted: KEY IN DETECT ON

When key is removed: KEY IN DETECT OFF




WITHOUT CONSULT-II

Check voltage between smart entrance control unit harness connector M41 terminal 5 (B/R) and ground.

Condition	Voltage [V]
Key is inserted from ignition key cylinder.	Approx. 12
Key is removed from ignition key cylinder.	0

OK or NG

- OK >> Replace smart entrance control unit.
 NG >> GO TO 9.




9. CHECK KEY SWITCH (INSERT)

1. Disconnect key switch connector.
2. Check continuity between 1 and 2.

Condition	Continuity
Key is inserted from ignition key cylinder.	Yes
Key is removed from ignition key cylinder.	No

OK or NG

- OK >> Check the following.
- 10A fuse [No. 12, located in fuse block (J/B)]
 - Harness for open or short between key switch and fuse
 - Harness for open or short between smart entrance control unit and key switch
- NG >> Replace key switch.



INTERIOR ROOM LAMP

Interior Room Lamp Timer Does Not Cancel

EKS0054V


1. CHECK IGNITION ON SIGNAL

WITH CONSULT-II

Check ignition switch ON signal ("IGNITION SW") in "DATA MONITOR" mode with CONSULT-II.

When ignition switch is ON: IGNITION SW ON

When ignition switch is OFF: IGNITION SW OFF



WITHOUT CONSULT-II

1. Disconnect smart entrance control unit connector.
2. Check voltage between smart entrance control unit and ground.


Terminals		Ignition switch position			
(+) (–)					
Connector	Terminal (wire color)	OFF	ACC	ON	
M42	29 (Y/G)	0V	0V	Battery voltage	

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse



INTERIOR ROOM LAMP


2. CHECK DOOR SWITCH INPUT SIGNAL

WITH CONSULT-II

Check driver door switch signal ("DR DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When driver's door switch is open: DR DOOR SW ON

When driver's door switch is closed: DR DOOR SW OFF




WITHOUT CONSULT-II

1. Connect smart entrance control unit connector.
2. Check voltage between smart entrance control unit harness connector M42 terminal 43 (R/W) and ground.

Condition	Voltage [V]
Driver's door is open.	0
Driver's door is closed.	Approx. 12

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.




3. CHECK DRIVER SIDE DOOR SWITCH

1. Disconnect smart entrance control unit connector.
2. Check continuity between front door switch (driver side) harness connector B16 terminal 1 and ground.

Condition	Continuity
Front door switch (driver side) is ON (Open)	Yes
Front door switch (driver side) is OFF (Closed)	No

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and driver side door switch.
NG >> Replace driver side door switch.



INTERIOR ROOM LAMP

4. CHECK DOOR LOCK/UNLOCK SWITCH

WITH CONSULT-II

Check door lock/unlock switch signal ("CDL LOCK SW" or "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT-II.

When door lock/unlock is locked : CDL LOCK SW ON
: CDL UNLOCK SW OFF
When door lock/unlock is unlocked : CDL LOCK SW OFF
: CDL UNLOCK SW ON


DATA MONITOR	
MONITOR	
CDL LOCK SW	OFF
CDL UNLOCK SW	ON

MKIB0198E

WITHOUT CONSULT-II

Check voltage between smart entrance control unit harness connector.

Terminals		Condition (Door lock/ unlock switch)	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
M41	13 (GY)	Locked	0
		Unlocked	Approx. 12
	14 (BR/Y)	Locked	Approx. 12
		Unlocked	0



OK or NG

OK >> Replace smart entrance control unit.
NG >> GO TO 5.

5. CHECK DOOR LOCK/UNLOCK SWITCH

- Disconnect door lock/unlock switch harness connector.
- Check continuity between door lock/unlock switch harness connector M102 terminals 2 and 3.


Condition	Continuity
Door lock/unlock switch is locked.	No
Door lock/unlock switch is unlocked.	Yes

- Check continuity between door lock/unlock switch harness connector M102 terminals 1 and 3.

Condition	Continuity
Door lock/unlock switch is locked.	Yes
Door lock/unlock switch is unlocked.	No

OK or NG

OK >> Check harness for open or short between smart entrance control unit and door lock/unlock switch.
NG >> Replace lock/unlock switch.



INTERIOR ROOM LAMP


Bulb Replacement INTERIOR ROOM LAMP

EKS0054W

Refer to [LT-124, "SPOT LAMP"](#) .

STEP LAMP

1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb.



ASHTRAY

Removal and installation, refer to [LT-121, "ASHTRAY"](#) .


Removal and Installation INTERIOR ROOM LAMP

EKS0054X

Refer to [LT-124, "SPOT LAMP"](#) .


STEP LAMP

1. Using a clips driver or a suitable tool, press and remove the metal clip of the step lamp.
2. Disconnect the interior step lamp connector.



ASHTRAY

1. Remove the A/T finisher. Refer to [IP-3, "INSTRUMENT PANEL ASSEMBLY"](#)
2. Remove the console box (front, rear).
3. Remove the instrument finisher E.
4. Remove the cluster lid C.
5. Remove the audio assembly.
6. Turn the bulb socket counterclockwise and unlock it.



SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS



SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

PFP:26470

Wiring Diagram — INT/L —

EKS004TZ

LT-INT/L-01





REFER TO THE FOLLOWING.

(M2) -FUSE BLOCK-
JUNCTION BOX (J/B)

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

LT-INT/L-02



MKWA0783E

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

Bulb Replacement

SPOT LAMP

EKS004U0


1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb.

Interior room lamp

: 12V - 7W

Spot lamp

: 12V - 5W



TRUNK ROOM LAMP

For removal and installation, refer to [LT-124, "TRUNK ROOM LAMP"](#) .

Trunk room lamp

: 12V - 3.4W

LUGGAGE ROOM LAMP

For removal and installation, refer to [LT-125, "LUGGAGE ROOM LAMP"](#) .

Luggage room lamp


: 12V - 10W

Removal and Installation

SPOT LAMP


EKS004U1

1. Using a clips driver or a suitable tool, press and remove the hook of the spot lamp.
2. Disconnect the spot lamp connector.



TRUNK ROOM LAMP


1. Remove the lens disengage nail A.
2. Pushing the nail B, remove the trunk room lamp.
3. Disconnect the trunk room lamp connector.



SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

LUGGAGE ROOM LAMP

1. Using a clips driver or a suitable tool. Press and remove the clip of the luggage room lamp.
2. Disconnect the luggage room lamp connector.



A

B

C

D

E

F

G

H

I

J

LT

L

M

CAN COMMUNICATION

CAN COMMUNICATION

PFP:23710

System Description

EKS005M5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS005M6

Body type	Sedan/Wagon/Hatch back												
Axle	2WD												
Engine	QR20DE			QG18DE		QR20DE		QG18 DE	YD22 DDTi	QG16 DE	QG18 DE	QR20 DE	YD22D DTi
Transmission	CVT			A/T		6M/T		5M/T	6M/T	5M/T		6M/T	
Brake control	ESP		ABS	ABS	ESP	ESP				ABS			
ICC system	Appli- cable	Not applicable				Appli- cable	Not applicable						
CAN communication unit													
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×	×								
ESP/TCS/ABS control unit	×	×			×	×	×	×	×				
ABS actuator and electric unit (control unit)			×	×						×	×	×	×
Data link con- nector	×	×	×	×	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×			×	×	×	×	×				
Smart entrance control unit	×	×	×	×	×	×	×	×	×	×	×	×	×
ICC unit	×					×							
ICC sensor	×					×							
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×
Can communica- tion type	<u>LT-127.</u> <u>"TYP</u> <u>E 1/</u> <u>TYPE</u> <u>8"</u>	<u>LT-129.</u> <u>"TYP</u> <u>E 2/</u> <u>TYPE</u> <u>9"</u>	<u>LT-130.</u> <u>"TYP</u> <u>E 3/</u> <u>TYPE</u> <u>10"</u>	<u>LT-132.</u> <u>"TYP</u> <u>E 4/</u> <u>TYPE</u> <u>11"</u>	<u>LT-135.</u> <u>"TYP</u> <u>E 15/</u> <u>TYPE</u> <u>18"</u>	<u>LT-137.</u> <u>"TYP</u> <u>E 16/</u> <u>TYPE</u> <u>19"</u>	<u>LT-133, "TYPE 5,TYPE</u> <u>17/TYPE 12,TYPE 20"</u>			<u>LT-134, "TYPE 6,TYPE 7/TYPE</u> <u>13,TYPE 14"</u>			


×:Applicable

CAN COMMUNICATION


TYPE 1/TYPE 8

System diagram

- LHD models (Type 1)



- RHD models (Type 8)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
Engine speed signal	T		R			R		R
Accelerator pedal position signal	T	R	R			R		
Closed throttle position signal	T	R				R		
ICC steering switch signal	T					R		
Shift pattern signal		T				R		
Parking brake switch signal			T			R		
ICC system display signal						T		R
ICC sensor signal						R	T	
ESP operation signal	R	R	T			R		
TCS operation signal	R	R	T			R		
ABS operation signal	R	R	T			R		
Stop lamp switch signal		R	T					
Steering wheel angle sensor signal			R	T				
Wheel speed sensor signal			T			R		
Rear window defogger signal	R				T			
Heater fan switch signal	R							T
Air conditioner switch signal	R							T
Primary pulley revolution signal	R	T	R			R		
Secondary pulley revolution signal	R	T	R			R		

CAN COMMUNICATION


Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
ICC operation signal	R					T		
Brake switch signal		R						T
MI signal	T							R
Current gear position signal		T						R
Engine coolant temperature signal	T					R		R
Fuel consumption signal	T							R
Vehicle speed signal		R	T					
			T					R
	R							T
Seat belt reminder signal					R			T
Lighting switch position signal					T			R
Flashing indicator signal					T			R
Engine cooling fan speed signal	T				R			
Child lock indicator signal					T			R
Door switches state signal					T			R
A/C compressor signal	T				R			

CAN COMMUNICATION


TYPE 2/TYPE 9

System diagram

- LHD models (Type 2)



- RHD models (Type 9)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Engine speed signal	T		R			R
Accelerator pedal position signal	T	R	R			
Closed throttle position signal	T	R				
ESP operation signal	R	R	T			
TCS operation signal	R	R	T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal		R	T			
			T			R
	R					T


CAN COMMUNICATION

Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Seat belt reminder signal					R	T
Lighting switch position signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
A/C compressor signal	T				R	
ASCD main switch signal	T					R
ASCD cruise signal	T					R


TYPE 3/TYPE 10

System diagram

- LHD models (Type 3)



- RHD models (Type 10)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance con- trol unit	Combination meter
Engine speed signal	T				R
Closed throttle position signal	T	R			
ABS operation signal	R	R	T		
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		R	T		
			T		R
	R				T
Seat belt reminder signal				R	T
Lighting switch position signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
A/C compressor signal	T			R	
ASCD main switch signal	T				R
ASCD cruise signal	T				R
Accelerator pedal position signal	T	R			

A

B

C

D

E

F

G

H

I

J

LT

L


M

CAN COMMUNICATION


TYPE 4/TYPER 11

System diagram

- LHD models (Type 4)



- RHD models (Type 11)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Lighting switch position signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
A/C compressor signal	T			R	
ASCD main switch signal	T				R
ASCD cruise signal	T				R


CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Accelerator pedal position signal	T	R			
Output shaft revolution signal	R	T			


TYPE 5,TYPE 17/TYPE 12,TYPE 20

System diagram

- LHD models (Type 5,Type 17)



- RHD models (Type 12,Type 20)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Accelerator pedal position signal	T	R			
ESP operation signal	R	T			
TCS operation signal	R	T			
ABS operation signal	R	T			
Steering wheel angle sensor signal		R	T		
Rear window defogger signal ^{*2}	R			T	
Heater fan switch signal ^{*2}	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T

CAN COMMUNICATION

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Lighting switch position signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
A/C compressor signal	T			R	
ASCD main switch signal* ²	T				R
ASCD cruise signal* ²	T				R
Glow lamp signal* ¹	T				R


*1:YD22DDTi engine model only

*2:Except YD22DDTi engine models


TYPE 6,TYPE 7/TYPE 13,TYPE 14

System diagram

- LHD models (Type 6,Type 7)



- RHD models (Type 13,Type 14)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (con- trol unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal* ²	R		T	
Heater fan switch signal* ²	R			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal* ¹	T			R

CAN COMMUNICATION

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Lighting switch position signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
A/C compressor signal	T		R	
ASCD main switch signal ^{*2}	T			R
ASCD cruise signal ^{*2}	T			R


*1:YD22DDTi engine model only

*2:Except YD22DDTi engine models


TYPE 15/TYPE 18

System diagram

- LHD models (Type 15)



- RHD models (Type 18)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ESP / TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T		R			R
Accelerator pedal position signal	T	R	R			

CAN COMMUNICATION


Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
ESP operation signal	R		T			
TCS operation signal	R		T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Lighting switch position signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
A/C compressor signal	T				R	
ASCD main switch signal	T					R
ASCD cruise signal	T					R
Output shaft revolution signal	R	T				

CAN COMMUNICATION


TYPE 16/TYPE 19

System diagram

- LHD models (Type 16)



- RHD models (Type19)



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sensor	Combination meter
Engine speed signal	T	R			R		R
Accelerator pedal position signal	T	R			R		
Closed throttle position signal	T				R		
ICC steering switch signal	T				R		
Parking brake switch signal		T			R		
ICC system display signal					T		R
ICC sensor signal					R	T	
ESP operation signal	R	T			R		
TCS operation signal	R	T			R		
ABS operation signal	R	T			R		
Stop lamp switch signal		T					
Steering wheel angle sensor signal		R	T				
Wheel speed sensor signal		T			R		
Rear window defogger signal	R			T			
Heater fan switch signal	R						T
Air conditioner switch signal	R						T
ICC operation signal	R				T		
Brake switch signal	R				T		
MI signal	T						R
Engine coolant temperature signal	T				R		R

CAN COMMUNICATION

Signals	ECM	ESP/TCS / ABS con- trol unit	Steering angle sen- sor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
Fuel consumption signal	T						R
Vehicle speed signal		T					R
	R						T
Seat belt reminder signal				R			T
Lighting switch position signal				T			R
Flashing indicator signal				T			R
Engine cooling fan speed signal	T			R			
Child lock indicator signal				T			R
Door switches state signal				T			R
A/C compressor signal	T			R			

BULB SPECIFICATIONS

BULB SPECIFICATIONS

PFP:26297

Headlamp

EKS003V6

Item		Wattage (W)
High/Low	Without xenon headlamp	55/55 (H7/H7)
	With xenon headlamp	55/35 (H7/D2R)

Exterior Lamp

EKS003V7

Item		Wattage (W)
Front combination lamp	Clearance lamp	5
Front turn signal lamp		21 (amber)
Side turn signal lamp		5
Fog lamp	Front fog lamp	55 (H11)
	Rear fog lamp	21
Rear combination lamp	Stop/Tail lamp	21/5
	Turn signal lamp	21
	Back-up lamp	21
License plate lamp		5
High-mounted stop lamp	Sedan	21
	Wagon	5
	Hatchback	LED (Not serviceable)

Interior Lamp/Illumination

EKS0054Y

Item	Wattage (W)
Interior room lamp	7
Spot lamp	5
Trunk room lamp (Sedan)	3.4
Luggage room lamp (Wagon)	10

BULB SPECIFICATIONS
