

A

EX

EX

C

SECTION
EXHAUST SYSTEM

CONTENTS

EXHAUST SYSTEM	2	REMOVAL	2	F
Checking Exhaust System	2	INSTALLATION	3	
Removal and Installation	2	Inspection After Installation	3	
F9Q EMGINE MODELS	2			G

EXHAUST SYSTEM


EXHAUST SYSTEM

PFP:20100

Checking Exhaust System

EBS00SIH

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage or deterioration.



Removal and Installation


EBS00SII

CAUTION:

- Be sure to use genuine exhaust system parts or equivalents which are specially designed for heat resistance, corrosion resistance, and shape.
- Perform the operation with the exhaust system fully cooled down because the system will be hot just after the engine stops.
- Be careful not to cut your hand on the insulator edge.

F9Q ENGINE MODELS

SEC. 200•208



1. Mounting rubber
4. Exhaust front tube

2. Main muffler
5. Exhaust center tube

3. Ring gasket

REMOVAL

- Disconnect each joint and mounting.

EXHAUST SYSTEM

INSTALLATION

- Install in the reverse order of removal.

CAUTION:

- Always replace exhaust gaskets with new ones when reassembling.
- If the insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the insulator, remove them.
- When installing the insulator avoid large gaps or interference between the insulator and each exhaust pipe.
- Remove deposits from the sealing surface of each connection. Connect them securely to avoid gas leakage.
- Temporarily tighten mounting nuts on the exhaust manifold side and mounting bolts on the vehicle side. Check each part for unusual interference, and then tighten them to the specified torque.
- When installing each mounting rubber, avoid twisting or unusual extension in up/down and right/left directions.

Inspection After Installation

EBS00SIJ

- With the engine running, check exhaust tube joints for gas leakage and unusual noises.
- Check to ensure that mounting brackets and mounting insulators are installed properly and free from undue stress. Improper installation could result in excessive noise and vibration.

EXHAUST SYSTEM
